

R&S® SMW-K50/-K51

TD-SCDMA, incl. TD-SCDMA

Enhanced Features

User Manual



1175676102

This document describes the following software options:

- R&S®SMW-K50/-K51
1413.4039.xx, 1413.4080.xx

This manual describes firmware version FW 4.70.026.xx and later of the R&S®SMW200A.

Contents

1	Preface	7
1.1	Documentation Overview	7
1.1.1	Getting Started Manual.....	7
1.1.2	User Manuals and Help.....	7
1.1.3	Tutorials.....	7
1.1.4	Service Manual.....	8
1.1.5	Instrument Security Procedures.....	8
1.1.6	Basic Safety Instructions.....	8
1.1.7	Data Sheets and Brochures.....	8
1.1.8	Release Notes and Open Source Acknowledgment (OSA).....	8
1.1.9	Application Notes, Application Cards, White Papers, etc.....	8
2	Welcome to the TD-SCDMA Digital Standard	9
2.1	Accessing the TD-SCDMA Dialog	10
2.2	Scope	10
2.3	Notes on Screenshots	10
3	About the TD-SCDMA Options	11
3.1	Required Options	11
3.2	About TD-SCDMA	11
3.3	Modulation System	12
3.3.1	TD-SCDMA Signal Structure (Frames and Time Slots).....	12
3.3.2	DwPTS and UpPTS.....	13
3.3.3	Structure of Traffic Burst.....	14
3.3.3.1	Burst Without Layer 1 Control Information.....	14
3.3.3.2	Burst with Layer 1 Control Information.....	15
4	TD-SCDMA Configuration and Settings	17
4.1	General Settings	18
4.2	Trigger Settings	20
4.3	Marker Settings	25
4.4	Clock Settings	26
4.5	Local and Global Connector Settings	28

4.6	Common Cell Configuration Settings.....	28
4.7	Predefined Settings.....	31
4.8	Cell Configuration.....	32
4.8.1	Common Settings.....	33
4.8.2	Slots.....	35
4.9	Enhanced Channels Settings.....	37
4.9.1	Broadcast Channels (BCH) Common Settings.....	37
4.9.2	Broadcast Channels (BCH) Details Settings.....	38
4.9.3	Dedicated Channels (DCH) Common Settings.....	39
4.9.4	Dedicated Channels (DCH) Details Settings.....	43
4.9.5	Transport Channel.....	44
4.9.6	RMC PLCCH Channel Settings.....	47
4.9.7	RMC HS-SICH Channel Settings.....	49
4.9.8	Bit and Block Error Insertion.....	50
4.10	HSDPA/HSUPA Settings.....	51
4.10.1	HSDPA Settings.....	52
4.10.2	HSUPA Settings.....	53
4.10.3	HS-SCCH Settings (HSDPA).....	55
4.10.4	Global Settings.....	56
4.10.5	Coding Configuration.....	57
4.10.6	Signal Structure.....	60
4.10.7	HARQ Setup.....	62
4.11	Slot Configuration.....	63
4.11.1	Common Settings.....	63
4.11.2	Channel Table.....	65
4.11.3	Code Domain.....	69
4.11.4	Channel Graph.....	71
4.12	DPCCH Settings.....	72
4.12.1	Slot Structure and Slot Format.....	73
4.12.2	TFCI Settings.....	74
4.12.3	Sync Shift Settings.....	75
4.12.4	E-UCCH Settings.....	76
4.12.5	TPC Settings.....	77

4.13 Slot Mode PRACH Settings.....	79
4.13.1 Common Settings.....	80
4.13.2 UpPTS Settings.....	81
4.13.3 RACH Message Part Settings.....	82
4.14 Filter / Clipping / ARB Settings.....	84
4.14.1 Filter Settings.....	85
4.14.2 Clipping Settings.....	86
4.14.3 ARB Settings.....	88
4.15 Power Ramping.....	89
5 Remote-Control Commands.....	91
5.1 General Commands.....	92
5.2 Filter/Clipping/ARB Settings.....	99
5.3 Trigger Settings.....	103
5.4 Marker Settings.....	107
5.5 Clock Settings.....	109
5.6 Predefined Settings.....	109
5.7 Cell Settings.....	111
5.8 Enhanced Channels of Cell 1.....	115
5.9 Channel Settings.....	131
5.10 HSDPA/HSUPA Settings.....	148
List of Commands.....	160
Index.....	165

1 Preface

1.1 Documentation Overview

This section provides an overview of the R&S SMW user documentation. Unless specified otherwise, you find the documents on the R&S SMW product page at:

www.rohde-schwarz.com/manual/smw200a

1.1.1 Getting Started Manual

Introduces the R&S SMW and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc. A printed version is delivered with the instrument.

1.1.2 User Manuals and Help

Separate manuals for the base unit and the software options are provided for download:

- Base unit manual
Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.
- Software option manual
Contains the description of the specific functions of an option. Basic information on operating the R&S SMW is not included.

The contents of the user manuals are available as help in the R&S SMW. The help offers quick, context-sensitive access to the complete information for the base unit and the software options.

All user manuals are also available for download or for immediate display on the Internet.

1.1.3 Tutorials

The R&S SMW provides interactive examples and demonstrations on operating the instrument in form of tutorials. A set of tutorials is available directly on the instrument.

1.1.4 Service Manual

Describes the performance test for checking the rated specifications, module replacement and repair, firmware update, troubleshooting and fault elimination, and contains mechanical drawings and spare part lists.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS, <https://gloris.rohde-schwarz.com>).

1.1.5 Instrument Security Procedures

Deals with security issues when working with the R&S SMW in secure areas. It is available for download on the Internet.

1.1.6 Basic Safety Instructions

Contains safety instructions, operating conditions and further important information. The printed document is delivered with the instrument.

1.1.7 Data Sheets and Brochures

The data sheet contains the technical specifications of the R&S SMW. It also lists the options and their order numbers and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/smw200a

1.1.8 Release Notes and Open Source Acknowledgment (OSA)

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation.

The open source acknowledgment document provides verbatim license texts of the used open source software.

See www.rohde-schwarz.com/firmware/smw200a

1.1.9 Application Notes, Application Cards, White Papers, etc.

These documents deal with special applications or background information on particular topics.

See www.rohde-schwarz.com/application/smw200a and www.rohde-schwarz.com/manual/smw200a

2 Welcome to the TD-SCDMA Digital Standard

The R&S SMW-K50/-K51 are firmware applications that add functionality to generate signals in accordance with the TD-SCDMA (3GPP TDD LCR) standard.

TD-SCDMA (3GPP TDD LCR) designates a mobile radio transmission method developed for 3G mobile communication by the China Wireless Telecommunication Standard group (CWTS). This standard is similar to the 3GPP TDD proposition, but with greater emphasis placed on GSM compatibility and with a chip rate limited to 1.28 Mcps. TD-SCDMA is one option of UTRA-TDD, called 1.28Mcps TDD or low chip rate (LCR) TDD.

The R&S SMW-K50 main features are:

- Configuration of up to four TD-SCDMA cells with variable switching point of uplink and downlink.
- Freely configurable channel table for each slot and simulation of the downlink and uplink pilot timeslot.
- Real time generation of one traffic channel and the SYNC channel on the downlink
- Slot modes "Dedicated" and "PRACH" on the uplink.
- Clipping for reducing the crest factor

The R&S SMW-K51 option TD-SCDMA (3GPP TDD LCR) enhanced MS/BS tests incl. HSDPA extends the TD-SCDMA signal generation with:

- Simulation of high-speed channels in the downlink (HS-SCCH, HS-PDSCH) and the uplink (HS-SICH)
- Channel coding for BCH in real time
- A reference measurement channel

This user manual contains a description of the functionality that the application provides, including remote control operation.

All functions not discussed in this manual are the same as in the base unit and are described in the R&S SMW user manual. The latest version is available at:

www.rohde-schwarz.com/manual/SMW200A

Installation

You can find detailed installation instructions in the delivery of the option or in the R&S SMW service manual.

2.1 Accessing the TD-SCDMA Dialog

To open the dialog with TD-SCDMA settings

- ▶ In the block diagram of the R&S SMW, select "Baseband > TD-SCDMA".

A dialog box opens that displays the provided general settings.

The signal generation is not started immediately. To start signal generation with the default settings, select "State > On".

2.2 Scope



Tasks (in manual or remote operation) that are also performed in the base unit in the same way are not described here.

In particular, it includes:

- Managing settings and data lists, like storing and loading settings, creating and accessing data lists, or accessing files in a particular directory.
- Information on regular trigger, marker and clock signals and filter settings, if appropriate.
- General instrument configuration, such as checking the system configuration, configuring networks and remote operation
- Using the common status registers

For a description of such tasks, see the R&S SMW user manual.

2.3 Notes on Screenshots

When describing the functions of the product, we use sample screenshots. These screenshots are meant to illustrate as many as possible of the provided functions and possible interdependencies between parameters. The shown values may not represent realistic usage scenarios.

The screenshots usually show a fully equipped product, that is: with all options installed. Thus, some functions shown in the screenshots may not be available in your particular product configuration.

3 About the TD-SCDMA Options

3.1 Required Options

The basic equipment layout for generating TD-SCDMA signals includes the:

- Standard or wideband baseband generator (R&S SMW-B10/-B9)
- Baseband main module (R&S SMW-B13) or wideband baseband main module (R&S SMW-B13XT)
- Frequency option (e.g. R&S SMW-B1003)
- Digital standard TD-SCDMA (R&S SMW-K50)
- Option TD-SCDMA enhanced (R&S SMW-K51)

To play back a signal from a waveform file created by the simulation software R&S WinIQSIM2, the corresponding R&S WinIQSIM2 digital standard option must be installed.

For more information, see data sheet.

3.2 About TD-SCDMA

TD-SCDMA is a mobile radio standard in which available bandwidth is divided among subscribers according to frequency (FDMA), time (TDMA) and code (CDMA). The same frequency is used for both directions of transmission (TDD). Each resource (i.e. a combination of frequency, code and time slot) can be used simultaneously by several base stations or user equipment provided the scrambling codes differ. A cell is understood to be a base station and all user equipment communicating with this base station. The R&S SMW simulates a maximum of four cells at the same frequency. The multi-carrier mode can be used to simulate more than four cells at the same frequency or cells at several frequencies.

HSDPA (high speed downlink packet access) mode enhances the TD-SCDMA standard by data channels with high data rates especially for multi-media applications.

The R&S SMW generates the TD-SCDMA signals in a combination of realtime mode (real time channels) and arbitrary waveform mode. Simulation of bit and block errors can be activated for the channels generated in real time. In arbitrary waveform mode, the signal is first calculated and then output. The R&S SMW simulates TD-SCDMA at the physical channel layer.

Parameters of the modulation system TD-SCDMA

Table 3-1: Parameters of the modulation system TD-SCDMA

Parameter	Value
Chip rate	1.28 Mcps
Carrier spacing	1.6 MHz

Parameter	Value
Data modulation	QPSK
Filter	Root-raised cosine (0.22)
Channel types	Downlink : <ul style="list-style-type: none"> • Primary Common Control Physical Channel (P-CCPCH) • Secondary Common Control Physical Channel (S-CCPCH) • Physical Forward Access Channel (F-FACH) • Downlink Pilot Time Slot (DwPTS) • Dedicated Physical Channel (DPCH) Uplink : <ul style="list-style-type: none"> • Physical Random Access Channel (P-RACH) • Uplink Pilot Time Slot (UpPTS) Dedicated Physical Channel (DPCH)
Data rates	17.6 kbps, 35.2 kbps, 70.4 kbps to 281.6 kbps depending on channel type
Number of channels	4 cells, each containing max. 7 active slots. Each slot with up to 16 DPCHs and 5 special channels.
Frame structure	Frame: 5 ms with 7 (traffic) time slots. Time slot (traffic): 675 μ s Time slot (DwPTS): 75 μ s Time slot (UpPTS): 125 μ s The number of symbols transmitted in a slot depends on the symbol rate.
Scrambling code	128 different codes with length of 16 chips
SYNC codes	32 different codes with length of 64 chips
SYNC1 codes	256 different codes with length of 128 chips
Basic midamble codes	128 different codes with length of 128 chips
Spreading code	"Orthogonal Variable Spreading Factor Code (OVSF)"; spreading factors 1, 2, 4, 8, 16

3.3 Modulation System

3.3.1 TD-SCDMA Signal Structure (Frames and Time Slots)

The TDSCDMA signal is organized in frames of 5 ms length. Each frame comprises seven traffic time slots (Ts0 to Ts6, each 0.675 ms) and two special time slots (DwPTS and UpPTS) for synchronization.




Figure 3-1: Structure of TDSCDMA frame

Ts0 is always allocated to the downlink, Ts1 to the uplink. The other time slots are divided between the two directions of transmission, the switching point being variable.

3.3.2 DwPTS and UpPTS

In the downlink pilot time slot (DwPTS), the base station sends one of 32 possible 64-chip SYNC codes. The SYNC code allows the user equipment to synchronize to the base station. At the same time, the SYNC code defines the value range for the scrambling code and the basic midamble code.




Figure 3-2: Structure of DwPTS

The real-valued SYNC sequence is converted into a complex-valued SYNC sequence by a rotating-vector operation.

This SYNC sequence is divided up into four symbols with 16 chips each. The symbols are phase-modulated (possible phases are 45°, 135°, 225° and 315°) in order to signal the frame number of the interleaver.

In the supplied software, all symbols are modulated with 45°.

The uplink pilot time slot (UpPTS) is sent by the user equipment to initiate a call with the base station (before a P-RACH is sent, for example). The transmitted SYNC1 code is randomly selected from eight possible codes. If the base station does not respond to the UpPTS, the UpPTS is repeated in the next frame.




Figure 3-3: Structure of UpPTS

The UpPTS is a complex-valued signal resulting from the real SYNC1 sequence by a rotating-vector operation.

3.3.3 Structure of Traffic Burst

In time slots Ts0 to Ts6, bursts can be sent by the base station or the user equipment, i.e. in both directions of transmission. The burst structure is identical for both directions. There are two types of burst, however, which are described in the following.




Figure 3-4: Burst without Layer 1 Control Information

3.3.3.1 Burst Without Layer 1 Control Information

This type of burst can be used for all physical channels. It comprises two data fields, a midamble and a guard period.




Figure 3-5: Traffic burst without layer 1 control information

The useful data are

- Alternately fed to the I and the Q path (QPSK data modulation),
- Mapped from the 0/1 plane into the -1/+1 plane,
- Spread with the complex spreading code (spreading factor SF = 1, 2, 4, 8 or 16),
- Scrambled with the real-valued scrambling code,
- Weighted with the channel power and
- Filtered (root-raised cosine 0.22)

Since each user sends only one burst per frame, the following gross data rate is obtained:

$$Gross_data_Rate = \frac{704 * 2}{SF * 5ms} = 281600/SF \text{ kbit/s}$$

The midamble is obtained from the basic midamble by periodic repetition and shifting. For some channels, the midamble shift can be set in steps of eight chips. The basic midamble is 128 chips long, while the length for the midamble field in the time slot is 144 chips. Each scrambling code (setting parameter at cell level) is assigned a basic midamble code.

The midamble is not spread or scrambled.

No signal is transmitted during the guard period. This avoids crosstalk of the burst into the next time slot at the receiver end.

3.3.3.2 Burst with Layer 1 Control Information

This type of burst can be used only with DPCHs (dedicated physical channels). It differs from the "normal" burst only in that the data fields are shortened ahead of and after the midamble to enable the transmission of layer 1 control information.




Figure 3-6: Traffic burst with layer 1 control information

The burst consists of two fields of data symbols, a fixed-length 144 chip midamble, and control fields for Synchronization Shift (SS), Transmit Power Control (TPC), and Transport Format Indicator (TFCI). The timeslot is delimited by a 16-chip guard period (GP).

Each data field consists of a maximum of 352 chips.

The Transport Format Indicator field (TFCI) conveys transport format information to the receiver, which is used by the channel decoder to recover transport channels. The information is distributed into two segments in one burst (four segments in two burst = one frame)

The synchronization shift (SS) field is used to inform the other station of a shift of the burst time ("00" means that the sync shift is increased, "11" that it is decreased). The bits are transmitted in M consecutive frames. The shift value is a multiple k of $T_{chip}/8$. M and k are transmitted by signaling. The value for M (Sync Shift Repetition) can be selected.

Analogously to the Sync Shift field, the power control (TPC) field is used to initiate an increase or decrease of transmit power.

If the spreading factor SF is lower than 16, the control symbols are transmitted $16/SF$ times. Control symbols are treated like data symbols, i.e. they are spread and scrambled.

4 TD-SCDMA Configuration and Settings

- ▶ To access the TD-SCDMA settings, select "Baseband > TD-SCDMA".

Tip: The dialog is comprehensive. To simplify the description and the orientation through this documentation, the headings of the following section follow a common naming convention:

`<DialogName/TabName>< - ><SourceDialog>`


This common structure is intended to identify your current location in the dialog.

The remote commands required to define these settings are described in [Chapter 5, "Remote-Control Commands"](#), on page 91.

●	General Settings	18
●	Trigger Settings	20
●	Marker Settings	25
●	Clock Settings	26
●	Local and Global Connector Settings	28
●	Common Cell Configuration Settings	28
●	Predefined Settings	31
●	Cell Configuration	32
●	Enhanced Channels Settings	37
●	HSDPA/HSUPA Settings	51
●	Slot Configuration	63
●	DPCCH Settings	72
●	Slot Mode PRACH Settings	79
●	Filter / Clipping / ARB Settings	84
●	Power Ramping	89

4.1 General Settings

- To access this dialog, select "Baseband > TD-SCDMA > General".



This dialog comprises the standard general settings, valid for the signal in both transmission directions.

State

Activates the standard and deactivates all the other digital standards and digital modulation modes in the same path.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma :STATe` on page 98

Set to Default

Calls the default settings. The values of the main parameters are listed in the following table.

Parameter	Value
State	Not affected by "Set to Default"
Link Direction	Downlink/Forward
Filter	Root Cosine
Clipping	Off
Power ramping	Cosine / 2 chips
Trigger	Auto

Remote command:

`[:SOURce<hw>] :BB:TDSCdma :PRESet` on page 96

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The filename and the directory, in which the settings are stored, are user-definable; the file extension is however predefined.

See also, chapter "File and Data Management" in the R&S SMW user manual.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:SETTing:CATalog? on page 96

[:SOURce<hw>] :BB:TDSCdma:SETTing:LOAD on page 97

[:SOURce<hw>] :BB:TDSCdma:SETTing:STORe on page 97

Generate Waveform File

With enabled signal generation, triggers the instrument to store the current settings as an ARB signal in a waveform file. Waveform files can be further processed by the ARB and/or as a multi-carrier or a multi-segment signal.

The filename and the directory it is stored in are user-definable; the predefined file extension for waveform files is *.wv.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:WAVeform:CREate on page 98

TD-SCDMA Version

Displays the current version of the TD-SCDMA standard.

The default settings and parameters provided are oriented towards the specifications of the version displayed.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:VERSion? on page 98

Chip Rate

Displays the system chip rate. This is fixed at 1.28 Mcps.

The output chip rate can be varied in the Filter/Clipping/ARB Settings dialog (see [Chapter 4.14.1, "Filter Settings"](#), on page 85).

Remote command:

[:SOURce<hw>] :BB:TDSCdma:CRATe? on page 93

Link Direction

Selects the transmission direction.

The settings of the basestation or the user equipment are provided in the following dialog section in accordance with the selection.

"Downlink/ Forward"	The transmission direction selected is basestation to user equipment. The signal corresponds to that of a base station.
"Uplink/ Reverse"	The transmission direction selected is user equipment to base station. The signal corresponds to that of a user equipment.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:LINK on page 94

Filter / Clipping / ARB Settings

Access to the dialog for setting baseband filtering, clipping and the sequence length of the arbitrary waveform component, see [Chapter 4.14, "Filter / Clipping / ARB Settings"](#), on page 84 .

Power Ramping...

Accesses the dialog for setting the power ramping, see [Chapter 4.15, "Power Ramping"](#), on page 89.

Remote command:

n.a.

4.2 Trigger Settings


This tab provides access to the settings necessary to select and configure the trigger, like trigger source and mode, trigger suppression, as well as to arm or trigger an internal trigger manually. The current signal generation status is displayed in the header of the dialog together with information on the enabled trigger mode. As in the "Marker" and "Clock" dialogs, this dialog provides also access to the settings of the related connectors.



This section focuses on the available settings.

For information on how these settings affect the signal, refer to section "Basics on ..." in the R&S SMW user manual.

- ▶ To access this dialog, select "Baseband > TD-SCDMA > Trigger In".



This dialog comprises the settings required for configuring the trigger signal.



Routing and enabling a trigger

The provided trigger signals are not dedicated to a particular connector. Trigger signals can be mapped to one or more USER x or T/M connectors.

Use the [Local and Global Connector Settings](#) to configure the signal mapping, the polarity, the trigger threshold and the input impedance of the input connectors.


To route and enable a trigger signal, perform the following *general steps*:

- Define the signal source and the effect of a trigger event.
Select the "Trigger In > Mode" and "Trigger In > Source".
- Define the connector where the selected signal is provided.
Use the "Global Connectors" settings.

Trigger Settings Common to All Basebands.....	21
Trigger Mode.....	21
Signal Duration Unit.....	22
Trigger Signal Duration.....	22
Running/Stopped.....	22
Arm.....	22
Execute Trigger.....	22
Trigger Source.....	23
Sync. Output to External Trigger/Sync. Output to Trigger.....	23
External Trigger Inhibit.....	24
Trigger Delay.....	24

Trigger Settings Common to All Basebands

To enable simultaneous signal generation in all basebands, the R&S SMW couples the trigger settings in the available basebands in any instrument's configuration involving signal routing with signal addition. For example, in MIMO configuration, routing and summing of basebands or of streams.

The icon  indicates that common trigger settings are applied.

You can access and configure the common trigger source and trigger mode settings in any of the basebands. An arm or a restart trigger event applies to all basebands, too. You can still apply different delay to each of the triggers individually.

Trigger Mode

Selects trigger mode, i.e. determines the effect of a trigger event on the signal generation.

For more information, refer to chapter "Basics" in the R&S SMW user manual.

- "Auto"
The signal is generated continuously.
- "Retrigger"
The signal is generated continuously. A trigger event (internal or external) causes a restart.
- "Armed Auto"
The signal is generated only when a trigger event occurs. Then the signal is generated continuously.

An "Arm" stops the signal generation. A subsequent trigger event (internal or external) causes a restart.

- "Armed Retrigger"
The signal is generated only when a trigger event occurs. Then the signal is generated continuously. Every subsequent trigger event causes a restart.
An "Arm" stops signal generation. A subsequent trigger event (internal or external) causes a restart.
- "Single"
The signal is generated only when a trigger event occurs. Then the signal is generated once to the length specified at "Signal Duration".
Every subsequent trigger event (internal or external) causes a restart.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma [:TRIGger] :SEQuence` on page 106

Signal Duration Unit

Defines the unit for describing the length of the signal sequence to be output in the "Single" trigger mode.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger:SLUNit` on page 105

Trigger Signal Duration

Enters the length of the signal sequence to be output in the "Single" trigger mode.

Use this parameter to output part of the signal deliberately, an exact sequence of the signal, or a defined number of repetitions of the signal.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger:SLENgth` on page 105

Running/Stopped

With enabled modulation, displays the status of signal generation for all trigger modes.

- "Running"
The signal is generated; a trigger was (internally or externally) initiated in triggered mode.
- "Stopped"
The signal is not generated and the instrument waits for a trigger event.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger:RMODe?` on page 104

Arm

Stops the signal generation until a subsequent trigger event occurs.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger:ARM:EXECute` on page 103

Execute Trigger

For internal trigger source, executes trigger manually.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger:EXECute` on page 103

Trigger Source

The following sources of the trigger signal are available:

- "Internal"
The trigger event is executed manually by the "Execute Trigger".
- "Internal (Baseband A/B)"
The trigger event is provided by the trigger signal from the other basebands. If common trigger settings are applied, this trigger source is disabled.
- "External Global Trigger"
The trigger event is the active edge of an external trigger signal provided and configured at the USER x connectors.
- "External Local Trigger"
The trigger event is the active edge of an external trigger signal provided and configured at the local T/M/C connector.
With coupled trigger settings, the signal has to be provided at the T/M/C1/2/3 connectors.
- "External Local Clock"
The trigger event is the active edge of an external local clock signal provided and configured at the local T/M/C connector.
With coupled trigger settings, the signal has to be provided at the T/M/C1 connector.
- "Baseband Sync In"
Option: R&S SMW-B9
In master-slave mode, slave instruments are triggered by the active edge of the synchronization signal.

"External Local Clock/Trigger" require R&S SMW-B10.


Remote command:

[:SOURce<hw>] :BB:TDSCdma:TRIGger:SOURce on page 105

Sync. Output to External Trigger/Sync. Output to Trigger

Enables signal output synchronous to the trigger event.


- "On"
Corresponds to the default state of this parameter.
The signal calculation starts simultaneously with the trigger event. Because of the processing time of the instrument, the first samples are cut off and no signal is output. After elapsing of the internal processing time, the output signal is synchronous to the trigger event.



- "Off"

The signal output begins after elapsing of the processing time. Signal output starts with sample 0. The complete signal is output.

This mode is recommended for triggering of short signal sequences. Short sequences are sequences with signal duration comparable with the processing time of the instrument.



In master-slave mode, this setting ensures that once achieved, synchronization is not lost if the baseband signal sampling rate changes.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger:EXTernal:SYNChronize:OUTPut`
on page 104

External Trigger Inhibit

Applies for external trigger signal or trigger signal from the other path.

Sets the duration with that any following trigger event is suppressed. In "Retrigger" mode, for example, a new trigger event does not cause a restart of the signal generation until the specified inhibit duration does not expire.

For more information, see chapter "Basics" in the R&S SMW user manual.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger[:EXTernal]:INHibit` on page 106
`[:SOURce<hw>] :BB:TDSCdma:TRIGger:OBASeband:INHibit` on page 104

Trigger Delay

Delays the trigger event of the signal from:

- The external trigger source
- The other path
- The other basebands (internal trigger), if common trigger settings are used.

Use this setting to:

- Synchronize the instrument with the device under test (DUT) or other external devices
- Postpone the signal generation start in the basebands compared to each other
- Compensate delays and align the signal generation start in multi-instrument setup

For more information, see chapter "Basics on ..." in the R&S SMW user manual.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:TRIGger[:EXTernal]:DELay` on page 106
`[:SOURce<hw>] :BB:TDSCdma:TRIGger:OBASeband:DELay` on page 104

4.3 Marker Settings


This tab provides access to the settings necessary to select and configure the marker output signal, like the marker mode or the marker delay settings.



This section focuses on the available settings. For information on how these settings affect the signal, refer to section "Basics on ..." in the R&S SMW user manual.

Access:

- ▶ Select "Baseband > TD-SCDMA > Marker".



This dialog comprises the settings required for configuring the marker mode and marker delay.



Routing and enabling a marker

The provided marker signals are not dedicated to a particular connector. They can be mapped to one or more USER x or T/M connectors.

To route and enable a marker signal, perform the following *general steps*:

- Define the shape of the generated marker, i.e. select the "Marker > Mode".
- Define the connector where the selected signal is provided. Use the [Local and Global Connector Settings](#).

[Marker Mode](#)..... 25
[Marker x Delay](#)..... 26

Marker Mode

Marker configuration for up to 3 markers. The settings are used to select the marker mode defining the shape and periodicity of the markers. The contents of the dialog change with the selected marker mode; the settings are self-explanatory.

"Radio Frame" A marker signal is generated every 10 ms (traffic channel frame clock).

"Chip Sequence Period (ARB)"


A marker signal is generated at the beginning of every arbitrary waveform sequence (depending on the set sequence length). The marker signal is generated regardless of whether an ARB component is used.

"System Frame Number (SFN) Restart"

A marker signal is generated at the start of every SFN period (every 4096 frames).

"On/Off Ratio"

A regular marker signal that is defined by an on/off ratio is generated. A period lasts one on and off cycle.



Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:ONTime` on page 108

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:OFFTime` on page 108

"User Period"

A marker signal is generated at the beginning of every user-defined period. The period is defined in "Period."

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:PERiod` on page 108

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:ONTime` on page 108

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:OFFTime` on page 108

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:PERiod` on page 108

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:MODE` on page 107

Marker x Delay

Delays the marker signal at the marker output relative to the signal generation start.

Variation of the parameter "Marker x Delay" causes signal recalculation.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:TRIGger:OUTPut<ch>:DELay` on page 108

4.4 Clock Settings


This dialog provides access to the settings necessary to select and configure the clock signal, like the clock source and clock mode.



This section focuses on the available settings.

For information on how these settings affect the signal, refer to section "Basics on ..." in the R&S SMW user manual.

- To access this dialog, select "Baseband > TD-SCDMA >Clock".



This dialog comprises the settings required for configuring the clock.



Defining the clock

The provided clock signals are not dedicated to a particular connector. They can be mapped to one or more USER x and T/M/C connectors.

Use the [Local and Global Connector Settings](#) to configure the signal mapping, the polarity, the trigger threshold, and the input impedance of the input connectors.

To route and enable a trigger signal, perform the following *general steps*:

- Define the signal source, that is select the "Clock > Source".
- Define the connector where the selected signal is provided.
Use the [Local and Global Connector Settings](#).

Clock Source

Selects the clock source.

- "Internal"
The instrument uses its internal clock reference.
- "External Local Clock"
Option: R&S SMW-B10
The instrument expects an external clock reference at the local T/M/C connector.

"External Local Clock" requires R&S SMW-B10.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:CLOCK:SOURce` on page 109

Clock Mode

Option: R&S SMW-B10

Sets the type of externally supplied clock.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:CLOCK:MODE` on page 109

Measured External Clock

Provided for permanent monitoring of the enabled and externally supplied clock signal.

Remote command:

`CLOCK:INPut:FREQuency?`

4.5 Local and Global Connector Settings


Each of the "Trigger In", "Marker" and "Clock" dialogs and the "Trigger Marker Clock" dialog provides a quick access to the related connector settings.



See also chapter "Local and Global Connector Settings" in the user manual.

4.6 Common Cell Configuration Settings

- To access this dialog select "Baseband > TD-SCDMA > Cells".



In this dialog, the cells can be set to the predefined settings, parameters of one cell can be copied to another cell, and the total power can be set to 0 dB. Each cell can be activated or deactivated. Active cells are highlighted in blue. Clicking a cell opens the configuration dialog for setting the cell parameters.

Provided are the following settings:

Reset All Cells

Resets all cells to the predefined settings. The reset applies to the selected link direction. The following table gives an overview of the settings. The preset value for each parameter is specified in the description of the remote-control commands.

Parameter	Value
"Cell Configuration"	
State	Off


Parameter	Value
(Use) Scrambling Code	On
Scrambling Code (value)	0
SYNC-DL Code	0
SYNC-UL Code	0
Basic Midamble Code ID	0
Number of Users	16
Switching Point	3
DwPTS Power	0.0 dB
"Slot Configuration"	
State	Off
Slot Mode (only in uplink)	Dedicated
Channel Configuration	
State	Off
"Channel Type"	Depending on channel number
Current User	1
Slot Format	0
Spreading Factor	16
Spreading Code	0
Power	0 dB
Data Source	PRBS: PN9, Data Pattern: 0
Number of TFCI bits	0
TFCI Value	0
Number of Sync Shift & TPC bits	0 & 0
Sync Shift Pattern	1
Sync Shift Repetition M	1
TPC Source/TPC Pattern	01
Read Out Mode	Continuous

Remote command:

[:SOURce<hw>] :BB:TDSCdma:RESet on page 96

Copy Cell...

Copies the settings of a cell to a second cell.



"Copy From Source"

Selects the cell whose settings are to be copied.

"To Destination"

Selects the cell whose settings are to be overwritten.

"Accept"

Starts the copy process.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:COPIY:SOURce on page 92

[:SOURce<hw>] :BB:TDSCdma:COPIY:DESTination on page 92

[:SOURce<hw>] :BB:TDSCdma:COPIY:EXECute on page 93

Predefined Settings

Access the dialog for setting predefined configurations, see [Chapter 4.7, "Predefined Settings"](#), on page 31 .

Remote command:

n.a.

Test Setups/Models

Accesses the dialog for selecting one of the test models defined in the TD-SCDMA standard and the self-defined test setups.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:SETTing:TMODe1 on page 97

Adjust Total Power to 0dB

Sets the power of an enabled channel so that the total power of all the active channels is 0 dB. This does not change the power ratio among the individual channels.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:POWer:ADJust on page 94

Total Power

Displays the total power of the active channels for the selected link direction.

The total power is calculated from the power ratio of the powered up code channels with modulation on. If the value is not equal to 0 dB, the individual code channels are internally adapted so that the "Total Power" for achieving the set output level is 0 dB. The power ratios are retained.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:POWer [:TOTal] ? on page 94

Select Cell

Selects the cell and accesses the corresponding dialog with cell-related settings, see [Chapter 4.8, "Cell Configuration"](#), on page 32.

Remote command:

n.a.

Cell On / Cell Off


Activates or deactivates the cells.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:STATe on page 114

4.7 Predefined Settings

- ▶ To access this dialog, select "TD-SCDMA > Cells > Predefined Settings".



The settings provided in this dialog depend on the link direction and apply only to cell1.

With the "Predefined Settings" function, it is possible to create highly complex scenarios with just a few keystrokes. This function is of use if, say, just the envelope of the signal is of interest.

Use PCCPCH (Downlink Slot 0, code 0+1)

(This feature is available in the downlink only.)

Selects, if P-CCPCH is used in the scenario or not.

If P-CCPCH is used, both P-CCPCHs are activated in slot 0 with spreading code 0+1.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:PPARameter:PCCPch:STATe on page 111

Spreading Factor Dedicated Channels

Selects the spreading factor for the DPCHs.

The available spreading factors depend on the link direction.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN | UP:PPARameter:DPCH:SFACTOR`

on page 110

Number of Dedicated Channels

Sets the number of activated DPCHs.

The minimum number is 1 and the maximum number depends on the spreading factor:

Max. No. DPCH = 3 x "Spreading Factor"

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN | UP:PPARameter:DPCH:COUNT` on page 109

Crest Factor

Selects the desired range for the crest factor scenario.

The crest factor of the signal is kept in the desired range by varying the distribution of the channels inside one slot and in between several slots.

"Minimum"	The crest factor is minimized. The channels are distributed uniformly over the slots and over the code domain of the individual slot.
"Average"	An average crest factor is set. The channels are distributed uniformly over the slots and successively in the code domain of the individual slot.
"Worst"	The crest factor is set to an unfavorable value (i.e. maximum). The channels are distributed in clusters over the slots and successively in the code domain of the individual slot.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN | UP:PPARameter:DPCH:CRESt` on page 110

Accept

Presets the channel table of cell 1 with the parameters defined in the "Predefined Settings" dialog.

Remote command:


`[:SOURCE<hw>] :BB:TDSCdma:DOWN | UP:PPARameter:EXECute` on page 111

4.8 Cell Configuration

The "Cell" dialog provides the parameters for configuring general cell settings, and specific slot-related settings.

4.8.1 Common Settings

1. To access this dialog, select "Baseband > TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4 > Common".



This dialog comprises the common parameters required for configuring the cell.

State

Activates or deactivates the selected cell.

The number of the selected cell is displayed in the dialog header.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:STATe on page 114

Use (Scrambling Code)

Activates or deactivates the scrambling code.

The scrambling code is deactivated, for example, for test purposes.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SCODE:STATe on page 113

Scrambling Code

Sets the scrambling code. The scrambling code identifies the cell and is the starting value of the scrambling code generator.

The scrambling code is used for transmitter-dependent scrambling of the chip sequence. The value range is 0 to 127.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SCODE on page 113

Basic Midamble Code ID

Displays the basic midamble code ID of the cell.

The basic midamble code ID is derived from the scrambling code.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:MCODe? on page 112

DwPTS Mode/ UpPTS Mode

Selects whether to use the pilot timeslot and its power or not. In "Auto" and "On", the DwPTS/UpPTS is used. This is indicated in the "Select Slot in Subframe to Configure" graph.

For details regarding the DwPTS/UpPTS, see [Chapter 3.3.2, "DwPTS and UpPTS"](#), on page 13.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:DWPTs:MODE on page 111

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:DWPTs:STAtE? on page 112

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:UPPTs:MODE on page 111

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:UPPTs:STAtE? on page 112

DwPTS Power/ UpPTS Power

Sets the power of the downlink/uplink pilot timeslot.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:UPPTs:MODE on page 111 [:

SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:UPPTs:POWer on page 112

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:DWPTs:POWer on page 112

SYNC-DL Code

Displays the SYNC-DL code.

The SYNC-DL code is transmitted in the DwPTS (downlink pilot timeslot). It is used by the user equipment to synchronize to the base station.

The SYNC-DL code is derived from the scrambling code and the basic midamble code ID.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SDCOde? on page 113

Phase Rotation

Selects the phase rotation for the downlink pilots.

"Auto" Sets the default phase rotation sequence according to the presence of the P-CCPCH.

"S1" There is a P-CCPCH in the next four subframes.

"S2" There is no P-CCPCH in the next four subframes.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:PROTation on page 113

SYNC-UL Code

Sets the SYNC-UL code.

The SYNC-UL code is transmitted in the UpPTS. It is used by the base station to synchronize to the user equipment.

The SYNC-UL code is derived from the scrambling code and the basic midamble code ID.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SUCode on page 114

Number of Users

Selects the total number of users of the cell. The number of users influences the actual midamble sequence transmitted in the burst.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:USERS on page 115

Time Delay

(This feature is available for cell 2, 3, and 4 only)


Enters the time delay of the signal of the selected cell compared to the signal of cell 1.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:TDElay on page 114

4.8.2 Slots

1. To access this dialog, select "Baseband > TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4 > Slots".



In this dialog, the slots are selected for configuration.

Enhanced Channels...

(available for cell1 only)

Accesses the dialog for setting enhanced channel configurations, see [Chapter 4.9, "Enhanced Channels Settings"](#), on page 37.

Remote command:
n.a.

Switching Point

Sets the switching point between the uplink slots and the downlink slots in the frame. Slot 0 is always allocated to the downlink, Slot 1 is always allocated to the uplink.

In the "Select Slot in Subframe to Configure" section, the switching point is indicated by a red bar. The slots to the left of the red bar are generated for link direction downlink, to the right of the red bar for link direction uplink. Only the slots for one link direction are active at a time, the slots of the other link direction are inactive.

Select Slot in Subframe to Configure									
Slot 0	Dw PTS	GP	Up PTS	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6
<input checked="" type="checkbox"/> On				<input checked="" type="checkbox"/> On	<input type="checkbox"/> On	<input type="checkbox"/> On	<input type="checkbox"/> On	<input checked="" type="checkbox"/> On	<input checked="" type="checkbox"/> On
active slot downlink		inactive slot		active slot uplink					

The DwPTS is always active in downlink mode. The UpPTS is only active if PRACH is selected for the uplink slots.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SPOint on page 114

Select Slot in Subframe to Configure

Displays the slots of the cell.

Active slots are highlighted blue (downlink) and green (uplink). Select a slot in the subframe to access the dialog for configuring the channels of the selected slot, see [Chapter 4.11, "Slot Configuration"](#), on page 63.

Remote command:

n.a.

Slot Icon

Activates or deactivates the slot in the subframe.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:STATE on page 141

GP (Guard Period)

The base station sends 16 chips of GP in each subframe and is inserted between the DwPTS and UpPTS in each subframe. The GP is used to avoid the multipath interference.

Remote command:

n.a.

4.9 Enhanced Channels Settings

The "Enhanced Channels Settings" dialog provides the parameters required for configuring the enhanced state of the channel. The selected link direction determines the provided channel:

- For "Downlink / Forward" direction, the Broadcast Channels (BCH) parameters are provided
- For "Uplink / Reverse" direction, the Dedicated Channel (DCH) settings.


All further parameters are available for both link directions.

- [Broadcast Channels \(BCH\) Common Settings](#)..... 37
- [Broadcast Channels \(BCH\) Details Settings](#).....38
- [Dedicated Channels \(DCH\) Common Settings](#).....39
- [Dedicated Channels \(DCH\) Details Settings](#).....43
- [Transport Channel](#)..... 44
- [RMC PLCCCH Channel Settings](#)..... 47
- [RMC HS-SICH Channel Settings](#).....49
- [Bit and Block Error Insertion](#)..... 50

4.9.1 Broadcast Channels (BCH) Common Settings

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell 1".
3. In the "Slots" tab, select "Enhanced Channels > BCH Common".



The "Broadcast Channels (BCH)" tab contains the common settings for configuring and activating the enhanced state of the channel.

State (BCH)

Activates or deactivates P-CCPCH 1/2 channel coding.

When activated, Slot 0 is active with P-CCPCH 1 and 2 switched on. The data source is fixed to BCH.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:STATE on page 130

Coding Type (BCH)

Displays the coding scheme.

The coding scheme of P-CCPCH (BCH) is specified in the standard. The channel is generated automatically with the counting system frame number (SFN). The system information after the SFN field is provided by the selected data source.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:TYPE? on page 131

Mapping On Physical Channels: BCH mapped to <Slot> 0, P-CCPCH1/2

Displays the slots of Cell 1 used to transmit the broadcast channels. For BCH, Slot 0 is always used.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SLOTstate<ch0>?
on page 130

Spreading Code Selection (BCH)

Selects if the spreading code of the channels is set automatically or manually. For BCH, the spreading code is always set to "Auto" as the spreading code for the P-CCPCH is defined by the standard.

Remote command:


[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SCSMODE?
on page 129

4.9.2 Broadcast Channels (BCH) Details Settings

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell 1".

- In the "Slots" tab, select "Enhanced Channels > BCH Details".



This dialog comprises the detailed settings required for BCH configuration.

Slot Format

Displays the slot format of the selected channel.

A slot format defines the complete structure of a slot made of data and control fields. The slot format depends on the coding type selected.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SFormat?`
on page 130

Data Bits Per Frame (10 ms)

Displays the data bits in the DPDCH component of the DPCH frame at physical level. The value depends on the slot format.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:BPFrame?`
on page 126

4.9.3 Dedicated Channels (DCH) Common Settings

Access:

- Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
- In the "Cells" tab, select "Cell 1".

3. In the "Slots" tab, select "Enhanced Channels > DCH Common".

Slot 0	Dw PTS	GP	Up PTS	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6
<input type="checkbox"/> On				<input type="checkbox"/> On	<input type="checkbox"/> On	<input type="checkbox"/> On	<input checked="" type="checkbox"/> On	<input checked="" type="checkbox"/> On	<input type="checkbox"/> On

The "Dedicated Channels (BCH)" tab contains the general settings for configuring and activating the enhanced state of the channel.

State (DCH)

Activates or deactivates DCH channel coding.

When the state is set to On, it activates the slots selected in the "Mapping On..." graph below. The number and configuration of the DPCHs is defined by the selected coding type. State and slot format of the channels are preset. The data source is fixed to DCH.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:STATE
on page 125
```

Coding Type

Selects the channel coding.

The current TD-SCDMA specification defines four reference measurement channel (RMC) in the uplink. There are five measurement channel coding types in the downlink, which differ in the input data bit rate to be processed.

Also, special RMCs are defined for HSDPA, HSUPA, HS-SICH and PLCCH.

Select one of the predefined downlink RMCs to preconfigure the settings for UE tests according to 3GPP TS25.102, annex A.2.

Select one of the predefined uplink RMCs to preconfigure the settings for BS tests according to 3GPP TS25.142, annex A.

The selected coding type defines the number of slots selected in section "Mapping On Physical Channels: Select Slots To Use".

"RMC 12.2 kbps" Downlink/uplink 12.2 kbps measurement channel.

Note: If RMC12K2, RMC64K, RMC144K, or RMC384K are selected for the uplink, they are automatically converted to UP_RMCxxx.

"RMC 64 kbps"	Downlink/uplink 64 kbps measurement channel
"RMC 144 kbps"	Downlink/uplink 144 kbps measurement channel
"RMC 384 kbps"	Downlink/uplink 384 kbps measurement channel
"RMC 2048 kbps"	Downlink 2048 kbps measurement channel
"RMC PLCCH"	Downlink RMC PLCCH channel (see RMC PLCCH Channel Settings).
"HSDPA"	(downlink only) HSDPA reference measurement channel (see Chapter 4.10, "HSDPA/HSUPA Settings" , on page 51).
"RMC HS-SICH"	Uplink RMC for transport channel HS-SICH (see Chapter 4.9.7, "RMC HS-SICH Channel Settings" , on page 49)
"HSUPA"	(uplink only) HSUPA reference measurement channel (see Chapter 4.10, "HSDPA/HSUPA Settings" , on page 51).
"User"	The channel settings are user-definable

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:TYPE on page 126

Resource Units On Physical Layer

Displays the resource units on the physical layer needed to generate the selected channel.

The table below gives an overview of the used resource units (RU) depending on the selected `Coding Type`. The used "Number of Time Slots" and "Number of Channels" is also displayed by the corresponding parameters.

RMC	Resources units allocated	Description	Transport channels
Downlink			
RMC 12.2 Kbps	1TS (2*SF16) = 2RU/5ms	1 slot with 2 code channels using spreading factor 16	1DTCH + 1DCCH
RMC 64 Kbps	1TS (8*SF16) = 8RU/5ms	1 slot with 8 code channels using spreading factor 16	1DTCH + 1DCCH
RMC 144 Kbps	2TS (8*SF16) = 16RU/5ms	2 slots with 8 code channels using spreading factor 16	1DTCH + 1DCCH
RMC 384 Kbps	4TS (10*SF16) = 40RU/5ms	4 slots with 10 code channels using spreading factor 16	1DTCH + 1DCCH
RMC 2048 kbps	5TS (1*SF1) = 80RU/5ms (8PSK)	5 slots with 1 code channel using spreading factor 1	1DTCH + 1DCCH
RMC-PLCCH	1TS (1*SF16) = 1RU/5ms (QPSK)	1 slot with 1 code channel using spreading factor 16	1DTCH

RMC	Resources units allocated	Description	Transport channels
Uplink			
RMC 12.2 Kbps	1TS (1*SF8) = 2RU/5ms	1 slot with 1 code channel using spreading factor 8	1DTCH + 1DCCH
RMC 64 Kbps	1TS (1*SF2) = 8RU/5ms	1 slot with 1 code channel using spreading factor 2	1DTCH + 1DCCH
RMC 144 Kbps	2TS (1*SF2) = 16RU/5ms	2 slots with 1 code channel using spreading factor 2	1DTCH + 1DCCH
RMC 384 Kbps	4TS (1*SF2 + 1*SF8) = 40RU/5ms	4 slots with 2 code channel using spreading factor 2 and 8	1DTCH + 1DCCH
RMC HS-SICH	1TS (1*SF16) = 1RU/5ms	1 slot with 1 code channel using spreading factor 16	

See " [RMC Configuration](#) " on page 52 and " [E-DCH Fixed Reference Channel \(FRC\)](#) " on page 54 for an overview of the used resources units in HSDPA and HSUPA mode respectively.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:RUPLayer?
```

on page 124

Mapping On Physical Channels: Select Slots To Use

Displays the slots of Cell 1. The slots used to transmit the transport channel are highlighted.

The number of slots is determined by the selected coding type. If a slot is deactivated, another slot is activated automatically to keep the number of activated slots unchanged.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:SLOTstate<ch>
```

on page 125

Spreading Code Selection for Enhanced Channels

Selects the spreading code selection mode for the used transport channels.

"User" The spreading codes can be set manually.

"Auto" The spreading codes are distributed evenly over the slot domains to ensure the minimum crest factor.

Remote command:


```
[ :SOURCE<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:SCSMode
```

on page 125

4.9.4 Dedicated Channels (DCH) Details Settings

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward".
2. In the "Cells" tab, select "Cell 1".
3. In the "Slots" tab, select "Enhanced Channels > DCH Details".



This dialog comprises the detailed settings required for DCH configuration.

Number of Timeslots (DCH)

Sets the number of timeslots to be used.

The initial value is preset according to the selected [Coding Type](#).

Remote command:

`[: SOURCE<hw>] : BB : TDSCdma : DOWN | UP : CELL<st> : ENH : DCH : TSCount`
on page 126

Number of Channels (DCH)

Sets the number of channels to be used.

The initial value is preset according to the selected [Coding Type](#).

Remote command:

`[: SOURCE<hw>] : BB : TDSCdma : DOWN | UP : CELL<st> : ENH : DCH : CCount`
on page 120

Slot Format

Displays the slot format of the selected channel.

A slot format defines the complete structure of a slot made of data and control fields. The slot format depends on the coding type selected.

Remote command:

[:SOURce<hw>] :BB:TDSCdma :DOWN | UP:CELL<st> :ENH:DCH:SFORmat ?
on page 125

Data Bits Per Frame (10 ms)

Displays the data bits in the DPDCH component of the DPCH frame at physical level.
The value depends on the slot format.


Remote command:

[:SOURce<hw>] :BB:TDSCdma :DOWN | UP:CELL<st> :ENH:DCH:BPFRame ?
on page 120

4.9.5 Transport Channel

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell 1".
3. In the "Slots" tab, select:
 - a) "Enhanced Channels > BCH Details" or
 - b) "Enhanced Settings > DCH Details".
4. Select "DTCH".



This dialog comprises the detailed settings required for configuring the transport channels (TCHs).

The most important parameters of the TCH are displayed (transport block size and data source).

State

Displays the transport channel state.

Note: For BCH, only the DTCH component is active.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:STATE on page 123

Data Source

Selects the data source for the transport channel.

The following standard data sources are available:

- "All 0, All 1"
An internally generated sequence containing 0 data or 1 data.
- "PNxx"
An internally generated pseudo-random noise sequence.
- "Pattern"
An internally generated sequence according to a bit pattern.
Use the "Pattern" box to define the bit pattern.
- "Data List/Select DList"
A binary data from a data list, internally or externally generated.
Select "Select DList" to access the standard "Select List" dialog.
 - Select the "Select Data List > navigate to the list file *.dm_iqd > Select" to select an existing data list.
 - Use the "New" and "Edit" functions to create internally new data list or to edit an existing one.
 - Use the standard "File Manager" function to transfer external data lists to the instrument.

See also:

- Section "Modulation Data" in the R&S SMW user manual.
- Section "File and Data Management" in the R&S SMW user manual.
- Section "Data List Editor" in the R&S SMW user manual

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA on page 127

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:DATA on page 121

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:DSElect on page 127

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:DATA:DSElect on page 121

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:PATtern on page 128

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:DATA:PATtern on page 122

Transport Time Interval

Displays the number of frames into which a TCH is divided. This setting also defines the interleaver depth.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TTInterval?

on page 129

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:TTInterval on page 124

Transport Blocks

Displays the number of transport blocks for the TCH.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBCount?

on page 129

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:TBCount on page 123

Transport Block Size

Displays the size of the transport block at the channel coding input.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBSize?

on page 129

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:TBSize on page 124

Size Of CRC

Displays the type (length) of the CRC.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:CRCSize?

on page 126

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:CRCSize on page 120

Rate Matching Attribute

Displays the rate matching.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:RMATtribute?

on page 128

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:RMATtribute on page 123

Error Protection

Displays the error protection.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:EProtection?

on page 128

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:EProtection on page 122

Interleaver 1 State

Activates or deactivates the channel coding interleaver state 1 of the transport channel. Interleaver state 1 can be set independently in each TCH. Activation does not change the symbol rate.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:IONE
```

on page 122

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:IONE
```

on page 123

Interleaver 2 State

Activates or deactivates the channel coding interleaver state 2 off all the transport channels. Interleaver state 2 can only be set for all the TCHs together. Activation does not change the symbol rate.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:ITWO
```

on page 122


```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:ITWO
```

on page 123


4.9.6 RMC PLCCH Channel Settings

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward".
2. In the "Cells" tab, select "Cell 1".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > RMC PLCCH".
5. Select "DCH Details".



6. Select "Information Bits".



This dialog comprises the detailed settings required for DCH configuration of the RMC PLCCH channel.

Transmission Time Interval (TTI)

Displays the transmission time interval.

Remote command:

[\[:SOURCE<hw>\]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TTInterval?](#)
on page 117

Number of Sync Shift&TPC Information Bits

Displays the number of information bits used for sync shift and TPC. The RMC PLCCH do not contains data bits.

Remote command:

n.a.

Sync Shift Pattern

Sets the sync shift pattern. The pattern length is 21 bits.

Remote command:

[\[:SOURCE<hw>\]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:SSPattern](#)
on page 116

TPC Pattern

Sets the TPC pattern. The pattern length is 21 bits.

Remote command:

[\[:SOURCE<hw>\]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TPCPattern](#)
on page 117


Repetition Encoder

Displays the state of the repetition encoder.

Remote command:
n.a.

4.9.7 RMC HS-SICH Channel Settings

1. To access this dialog select "TD-SCDMA > General > Link Direction" > "**Uplink / Reverse**"
2. In the "Cells" tab, select "Cell 1".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > RMC HS-SICH".
5. Select "DCH Details"



This dialog comprises the detailed settings required for DCH configuration of the RMC HS-SICH channel.

Transmission Time Interval (TTI) – RMC HS-SICH

Displays the transmission time interval.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICH:TTIInterval?`
on page 118

CQI Modulation

Sets the CQI modulation.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICH:CQI:MODulation` on page 118

CQI Value

Sets the CQI value.

With the CQI (Channel quality indicator), the user equipment informs the base station about the received quality of downlink HS-PDSCH. Thus the base station can adapt the modulation and coding scheme to improve the signal quality.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:CQI:VALue
on page 118

ACK/NAK Pattern

Sets the ACK/NACK pattern. The pattern has a maximal length of 36 bits; a "1" corresponds to ACK, a "0" to NAK.


Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:ANPattern
on page 117

4.9.8 Bit and Block Error Insertion

Access:

1. Select "TD-SCDMA > Cells > Cell 1".
2. In the "Slots" tab, select "Enhanced Channels > DCH Error Insertion".



In this dialog, the bit error and the block error simulation are configured and activated.

State (Bit Error)

Activates or deactivates bit error generation.

Bit errors are inserted into the data fields of the enhanced channels. If channel coding is active, it is possible to select the layer in which the errors are inserted (physical or transport layer).

When the data source is read out, individual bits are inverted at random points in the data bitstream at the specified error rate to simulate an invalid signal.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:BIT:STATe  
on page 119
```

Bit Error Rate

Enters the bit error rate.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:BIT:RATE  
on page 119
```

Insert Errors On

Selects the layer in the coding process at which bit errors are inserted.

"Transport Layer"

Bit errors are inserted in the transport layer.
This selection is only available if channel coding is active.

"Physical Layer"

Bit errors are inserted in the physical layer.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:BIT:LAYer  
on page 118
```

State (Block Error)

Activates or deactivates block error generation.

The CRC checksum is determined and then the last bit is inverted at the specified error probability to simulate an invalid signal.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:BLOCK:STATe  
on page 119
```

Block Error Rate

Enters the block error rate.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:BLOCK:RATE  
on page 119
```

4.10 HSDPA/HSUPA Settings


The HSDPA settings are available in downlink transmission direction and "Coding Type > HSDPA".

The HSUPA settings are available in uplink transmission direction and "Coding Type > HSUPA".

4.10.1 HSDPA Settings

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell x".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > HSDPA"



The settings can be configured in the "DCH Details" dialog. The settings are divided into several sections, which are described below.

RMC Configuration

(HSDPA only)

Enables a predefined set of RMC channels or fully configurable user mode, see [Table 4-1](#).

Table 4-1: RMC configurations

RMC Config.	Modulation	Resources units allocated	Description	Transport channels
H-RMC 0.5 Mbps	QPSK	2TS (10*SF16) = 20RU/5ms	2 slots with 10 code channels using spreading factor 16	1H-DTCH
H-RMC 1.1 Mbps	QPSK	2TS (10*SF16) = 20RU/5ms	2 slots with 10 code channels using spreading factor 16	1H-DTCH
	16QAM	2TS (12*SF16) = 24RU/5ms	2 slots with 12 code channels using spreading factor 16	1H-DTCH

RMC Config.	Modulation	Resources units allocated	Description	Transport channels
H-RMC 1.6 Mbps	QPSK	3TS (10*SF16) = 30RU/5ms	3 slots with 10 code channels using spreading factor 16	1H-DTCH
	16QAM	3TS (12*SF16) = 36RU/5ms	3 slots with 12 code channels using spreading factor 16	1H-DTCH
H-RMC 2.2 Mbps	QPSK	4TS (10*SF16) = 40RU/5ms	4 slots with 10 code channels using spreading factor 16	1H-DTCH
	16QAM	4TS (12*SF16) = 48RU/5ms	4 slots with 12 code channels using spreading factor 16	1H-DTCH
H-RMC 2.8 Mbps	QPSK	5TS (10*SF16) = 50RU/5ms	5 slots with 10 code channels using spreading factor 16	1H-DTCH
	16QAM	5TS (12*SF16) = 50RU/5ms	5 slots with 12 code channels using spreading factor 16	1H-DTCH
H-RMC 64QAM	64QAM (Category 16UE)	3TS (14*SF16) = 42RU/5ms	3 slots with 14 code channels using spreading factor 16	1H-DTCH
	64QAM (Category 19UE)	5TS (14*SF16) = 70RU/5ms	5 slots with 14 code channels using spreading factor 16	1H-DTCH
	64QAM (Category 22UE)	5TS (14*SF16) = 70RU/5ms	5 slots with 14 code channels using spreading factor 16	1H-DTCH
User	-	-	-	-

Several parameters are automatically set, depending on the selected RMC.

However, it is also possible to change these parameters.

In this case, the value of the parameter "RMC Configuration" is automatically set to "User".

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:RMC
on page 149

4.10.2 HSUPA Settings

Access:

1. Select "TD-SCDMA > General > Link Direction > Uplink / Reverse"
2. In the "Cells" tab, select "Cell x".

3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > HSUPA".

The settings can be configured in the "DCH Details" dialog. The settings are divided into several sections, which are described below.

E-DCH Fixed Reference Channel (FRC)

(HSUPA only)

Selects a predefined E-DCH fixed reference channel or fully configurable user mode, see [Table 4-2](#).

Table 4-2: FRC configurations

FRC	Modulation	Resources units allocated	Description	Transport channels
1	QPSK	2TS(1*SF4) =2RU/5ms	2 slots with 1 code channel using spreading factor 4	1DTCH
2	QPSK	2TS(1*SF2) =2RU/5ms	2 slots with 1 code channel using spreading factor 2	1DTCH
3	16QAM	3TS(1*SF2) =3RU/5ms	3 slots with 1 code channel using spreading factor 2	1DTCH
4	16QAM	4TS(1*SF1) =2RU/5ms	4 slots with 1 code channel using spreading factor 1	1DTCH
User	-	-	-	-

Several settings are preconfigured according to the selected FRC.


Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:FRC` on page 152

4.10.3 HS-SCCH Settings (HSDPA)

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell x".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > HSDPA".
5. Select "DCH Details".



HS-SCCH State

(HSDPA only)

Enables/disables the HS-SCCH.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SCCH`
on page 150

UEID (H-RNTI)

(HSDPA only)

Sets the UE identity which is the HS-DSCH Radio network identifier(H-RNTI) defined in 3GPP TS25.331, "Radio resource control (RRC); Protocol Specification".


Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:UEID`
on page 151

4.10.4 Global Settings

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell x".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > HSDPA".
5. Select "DCH Details > Global Settings".



UE Category

Displays the UE category that is minimum required to receive the selected RMC or FRC.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:HSDPA | HSUPA:UECategory? on page 159

Maximum Information Bit Throughput /kbps

Displays maximum information bits sent in each TTI before coding.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:HSDPA | HSUPA:MIBT? on page 156

Number of HS-PDSCH/E-DCH Timeslots

Sets the number of timeslots.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:HSDPA | HSUPA:TSCount on page 159

Number of HS-PDSCH/E-DCH Codes per TS

Sets the number of physical channels per timeslot.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:CTSCount on page 154

Spreading Factor (FRC)

(HSUPA only)

Selects the spreading factor for the FRC.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:SFACTOR on page 153

Number of E-UCCH per TTI

(HSUPA only)

Sets the number of E-UCCH channels per TTI.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:EUCTTI on page 151

Slot Format

Displays the slot format of the selected channel.

A slot format defines the complete structure of a slot made of data and control fields. The slot format depends on the coding type selected.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:SFORMAT? on page 158

Transmission Time Interval (TTI)

Displays the transmission time interval (TTI).


Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:TTIINTERVAL? on page 159

4.10.5 Coding Configuration

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell x".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > HSDPA".
5. Select "DCH Details > Coding Configuration".



Data Source

Selects the data source for the HSDPA/HSUPA channels.

The following standard data sources are available:

- "All 0, All 1"
An internally generated sequence containing 0 data or 1 data.
- "PNxx"
An internally generated pseudo-random noise sequence.
- "Pattern"
An internally generated sequence according to a bit pattern.
Use the "Pattern" box to define the bit pattern.
- "Data List/Select DList"
A binary data from a data list, internally or externally generated.
Select "Select DList" to access the standard "Select List" dialog.
 - Select the "Select Data List > navigate to the list file *.dm_iqd > Select" to select an existing data list.
 - Use the "New" and "Edit" functions to create internally new data list or to edit an existing one.
 - Use the standard "File Manager" function to transfer external data lists to the instrument.

See also:

- Section "Modulation Data" in the R&S SMW user manual.
- Section "File and Data Management" in the R&S SMW user manual.
- Section "Data List Editor" in the R&S SMW user manual

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:HSDPA | HSUPA:DATA` on page 154

`[:SOURce<hw>] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:HSDPA | HSUPA:DATA:PATtern` on page 155

`[:SOURce<hw>] :BB:TDSCdma:DOWN | UP:CELL<st>:ENH:DCH:HSDPA | HSUPA:DATA:DSElect` on page 155

Modulation

Sets the modulation scheme for each HSDPA RMC or HSUPA FRC.

64QAM is not available for the HSUPA FRCs.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:MODulation on page 156

Number of Coded Bits Per TTI

Displays the number of bits after coding.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:NCBTti? on page 157

Transport Block Size Table

(HSDPA only)

Sets the transport block size table, according to the specification 3GPP TS 25.321.

The values available depend on the selected modulation.

Modulation	TBS Table	
	Downlink	Uplink
QPSK	category [1, 3] category [4, 6] category [7, 9] category [10,12] category [13, 15] category [16, 18] category [19, 21] category [22, 24]	category [1, 2] category [3, 6]
16QAM	category [4, 6] category [7, 9] category [10,12] category [13, 15] category [16, 18] category [19, 21] category [22, 24]	category [1, 2] category [3, 6]
64QAM	category [16, 18] category [19, 21] category [22, 24]	-

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TBS:TABLE on page 150

Transport Block Size Table 0

(HSUPA only)

Sets the transport block size table, according to the specification 3GPP TS 25.321, annex BC.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:TBS:TABLE
on page 153

Transport Block Size Index

Selects the index for the corresponding table, as described in 3GPP TS 25.321.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
TBS:INDEX on page 158

Information Bit Payload (Ninf)

Displays the payload of the information bit. i.e. transport block size. This value determines the number of transport layer bits sent in each TTI before coding.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
BPAYload? on page 153

Coding Rate

Displays the resulting coding rate.

The coding rate is calculated as a relation between the Information Bit Payload and "Number of Coded Bits per TTI".

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
CRATE? on page 154

Virtual IR Buffer Size (Per HARQ process)

(HSDPA only)

Sets the size of the virtual IR buffer.


Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:VIBSize
on page 151

4.10.6 Signal Structure

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell x".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > HSDPA".
5. Select "DCH Details > Signal Structure".



Inter TTI Distance

(HSDPA only)

Sets the inter-TTI distance. This is the distance between two packets in HSDPA packet mode and determines whether data is sent each TTI or there is a DTX transmission in some of the TTIs.

An "Inter TTI Distance" of 1 means continuous generation.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TTIDistance`
on page 151

Number of HARQ Processes

Sets the number of HARQ processes. This value determines the distribution of the payload in the subframes and depends on the "Inter TTI Distance".

A minimum of three HARQ Processes are required to achieve continuous data transmission.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA: HARQ:LENGTH` on page 155

Signaling Pattern

Displays the distribution of packets over time.

The "Signaling Pattern" displays a HARQ-Process cycle and is a sequence of HARQ-IDs and "-". An HARQ-ID indicates a packet, a "-" indicates no packet. The signaling pattern is cyclically repeated.

Long signaling patterns with regular repeating groups of HARQ-ID and "-" are not displayed completely. The displayed signaling pattern is shortened but the scheduling is performed according to the selected "Inter TTI Distance". Long signaling patterns with irregularity in the HARQ-ID and "-" groups are displayed completely.


Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SPATtern?
on page 150

4.10.7 HARQ Setup

Access:

1. Select "TD-SCDMA > General > Link Direction > Downlink / Forward"
2. In the "Cells" tab, select "Cell x".
3. In the "Slots" tab, select "Enhanced Channels > DCH Common".
4. Select "Coding Type > HSDPA".
5. Select "DCH Details > HARQ Setup".



HARQ Mode

Sets the HARQ simulation mode.

"Constant ACK"	New data is used for each new TTI. This mode is used to simulate maximum throughput transmission.
"Constant NACK"	Enables NACK simulation, i.e. depending on the sequence selected with parameter "Redundancy Version Sequence" packets are retransmitted. This mode is used for testing with varying redundancy version.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
HARQ:MODE on page 156

Redundancy Version Parameter

(for "HARQ Mode > Constant ACK")

Enters the redundancy version parameter.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:RVParameter on page 157
```

Redundancy Version Sequence

(for "HARQ Mode > Constant NACK")

Sets the retransmission sequence.

The sequence has a length of maximum 30 values, separated by commas. The sequence length determines the maximum number of retransmissions. New data is retrieved from the data source after reaching the end of the sequence.

For HSUPA, this parameter is read-only.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:RVSequence on page 157
```

Retransmission Sequence Number

(for HSUPA and "HARQ Mode > Constant ACK")

Sets the retransmission sequence number.

The value is fixed to 0.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSNumber? on page 152
```

Retransmission Sequence

(for HSUPA and "HARQ Mode > Constant NACK")

Sets the retransmission sequence.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSEquence on page 152
```


4.11 Slot Configuration

This "TD-SCDMA Cell/Slot..." dialog contains the parameters required for configuring the cell of the selected slot, providing the channel table with graphical display of the respective channel.

4.11.1 Common Settings

1. To access this dialog, select "TD-SCDMA > Cells".

2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".



This dialog comprises the common settings required for configuring and activating a slot. The selected link direction determines the provided parameters.

State

Activates or deactivates the selected slot. The index of the selected slot is displayed in the dialog header.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:STATE on page 141

Slot Mode

(This feature is available in the uplink only.)

Selects the slot mode.

"Dedicated" Selects the Dedicated mode. In this mode, the instrument generates a signal with a dedicated physical control channel (DPCCH) and up to six dedicated physical data channels (DPDCH). The signal is used for voice and data transmission.

"PRACH" In this mode, the instrument generates a single physical random access channel (PRACH). This channel is needed to set up the connection between the mobile and the base station. To set the PRACH parameters, see [Chapter 4.13, "Slot Mode PRACH Settings"](#), on page 79.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:MODE on page 141

4.11.2 Channel Table

1. To access this channel table, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".

Channel Type	Enhanced	Crt.User/Mid.Shift	Slot Fmt	Spred Fact	Spred Code	Power /dB	Data	DList / Pattern	DPCCH Settings	State	Dom Conf
0 P-CCPCH 1	Off	1/120	0	16	1	0.00	PN 9			On	
1 P-CCPCH 2	Off	1/120	0	16	2	0.00	PN 9			On	
2 S-CCPCH 1		1/120	0	16	1	0.00	PN 9		Config...	Off	
3 S-CCPCH 2		1/120	0	16	1	0.00	PN 9		Config...	Off	
4 FPACH		1/120	0	16	1	0.00	PN 9			Off	
5 PDSCH		1/120	0	16	1	0.00	PN 9		Config...	Off	

The channel table comprises the individual channel parameters, and displays the currently selected channel structure graphically.

The number of channels and the available channel types depend on the link direction. In downlink, Channels 0 to 5 are assigned to the special channels, with the allocation of the channels being fixed. In uplink, Channel 0 is assigned to a special channel, with the allocation of the channel being fixed. It is possible to simulate the signal of a base station that supports high-speed channels.

See [Table 4-3](#) and [Table 4-4](#) for overview of the supported channel types and their sequence in the TD-SCDMA channel table.

Table 4-3: Supported channel types (Downlink)

Index	Short form	Name	Function
0	P-CCPCH 1	Primary Common Control Phys. Channel 1	Transfers the system frame number (SFN) Timing reference for additional downlink channels Contains the BCH transport channel
1	P-CCPCH 2	Primary Common Control Phys. Channel 2	Transfers the system frame number (SFN) Timing reference for additional downlink channels Contains the BCH transport channel
2	S-CCPCH 1	Secondary Common Control Phys. Channel	

Index	Short form	Name	Function
3	S-CCPCH 2	Secondary Common Control Phys. Channel	
4	FPACH	Fast Physical Access Channel	
5	PDSCH	Phys. Downlink Shared Channel	
6-21	DPCH QPSK	Dedicated Phys. Channel Modulation QPSK	Transfers the user data and the control information
	DPCH 8PSK	Dedicated Phys. Channel Modulation 8PSK	
	HS-SCCH 1	High-Speed Shared Control Channel 1	
	HS-SCCH 2	High-Speed Shared Control Channel 2	
	HS-PDSCH (QPSK)	High-Speed Phys. Downlink Shared Channel QPSK	
	HS-PDSCH (16QAM)	High-Speed Phys. Downlink Shared Channel 16 QAM	
	HS-PDSCH (64QAM)	High-Speed Phys. Downlink Shared Channel 64QAM	
	PLCCH	Physical layer common control channel	
	E-AGCH	E-DCH Absolute Grant Channel	
	E-HICH	E-DCH Hybrid ARQ Indicator Channel	

Table 4-4: Supported channel types (Uplink)

Index	Short form	Name	Function
0	PUSCH	Phys. Uplink Shared Channel	
1-16	DPCH QPSK	Dedicated Phys. Channel Modulation QPSK	
	DPCH 8PSK	Dedicated Phys. Channel Modulation 8PSK	
	HS-SICH	High-Speed Shared Information Channel	
	E-PUCH (QPSK)	E-DCH Uplink Physical Channel (QPSK)	
	E-PUCH (16QAM)	E-DCH Uplink Physical Channel (16QAM)	
	E-RUCCH	E-DCH Random Access Uplink Control Channel	

Channel Number

Displays the consecutive channel numbers. The range depends on the selected transmission direction.

All available channels are displayed, even inactive channels. Each channel is activated/deactivated by the "State" button.

Remote command:
n.a.

Channel Type

Selects the channel type.

In the uplink, the channel type is fixed for channel number 0.

In the downlink, the channel type is fixed for channel numbers 0 to 5.

For the remaining numbers, the choice lies between the relevant standard channels and the high-speed channels (see [Table 4-3](#) and [Table 4-4](#)).

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:TYPE on page 140

Enhanced

Displays the enhanced state. If the enhanced state is set to on, the channel coding cannot be changed.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:ENHanced? on page 138

Crt.User/Mid.Shift

Enters the value for the user and displays the midamble shift.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:USER on page 140

Slot Format

Enters the slot format for the selected channel.

The range of the values depends on the channel selected. For DPCH 8PSK channels, for example, the value range for the slot formats is 0 to 24.

A slot format defines the complete structure of a slot made of data and control fields and includes the symbol rate.

Parameters set via the slot format can then be changed individually.

The structure of the channel currently selected is displayed in a graphic above the channel table.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:SFORMAT on page 139

Sprd. Fact.

Enters the spreading factor for the selected channel. The selection depends on the channel type and interacts with the slot format.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:SFACTOR on page 139
```

Sprd. Code

Enters the spreading code for the selected channel. The code channel is spread with the set spreading code. The range of values for the spreading code depends on the channel type and the spreading factor. Depending on the channel type, the range of values can be limited.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:SCODE on page 139
```

Power/dB

Sets the channel power in dB.

The power entered is relative to the powers outputs of the other channels. If "Adjust Total Power to 0 dB" is executed (top level of the TD-SCDMA dialog), all the power data is relative to 0 dB.

The value range is -80 dB to 0 dB.

Note: The maximum channel power of 0 dB applies to non-blanked channels (duty cycle 100%). With blanked channels, the maximum value can be increased to values greater than 0 dB.

Use the parameter "Adjust Total Power" to increase the power to a maximum value of $10 \cdot \log_{10}(1/\text{duty_cycle})$

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:POWER on page 138
```

Data

Selects data source.

The following standard data sources are available:

- "All 0, All 1"
An internally generated sequence containing 0 data or 1 data.
- "PNxx"
An internally generated pseudo-random noise sequence.
- "Pattern"
An internally generated sequence according to a bit pattern.
Use the "Pattern" box to define the bit pattern.
- "Data List/Select DList"
A binary data from a data list, internally or externally generated.
Select "Select DList" to access the standard "Select List" dialog.
 - Select the "Select Data List > navigate to the list file *.dm_iqd > Select" to select an existing data list.

- Use the "New" and "Edit" functions to create internally new data list or to edit an existing one.
- Use the standard "File Manager" function to transfer external data lists to the instrument.

See also:

- Section "Modulation Data" in the R&S SMW user manual.
- Section "File and Data Management" in the R&S SMW user manual.
- Section "Data List Editor" in the R&S SMW user manual

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DATA on page 134

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DATA:DSElect on page 134

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DATA:PATtern on page 134

DPCCH Settings

Accesses the dialog for configuring the control fields of the selected channel.

The selected slot format predetermines the setting of the control fields.

So a change is also made to the control fields by changing the slot format and vice versa.

The dialog is described in [Chapter 4.12, "DPCCH Settings"](#), on page 72

Remote command:

n.a.

State

Activates or deactivates the channel.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:STATE on page 140

Dom. Conf.

Displays whether the channel has a code domain conflict with one of the overlying channels (with lower channel number).

If there is a conflict, a warning icon appears. You can find the current code domain assignment graphically displayed in the "Code Domain" tab (see [Chapter 4.11.3, "Code Domain"](#), on page 69).

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:DCONflict? on page 141

4.11.3 Code Domain

The channelization codes are taken from a code tree of hierarchical structure (see [Figure 4-1](#)). The higher the spreading factor, the smaller the symbol rate and vice versa.

The product of the spreading factor and symbol rate is constant and always yields the chip rate.

The outer branches of the tree (right-most position in the figure) indicate the channelization codes for the smallest symbol rate (and thus the highest spreading factor). Channelization codes with smaller spreading factor are contained in the codes with larger spreading factor in the same code branch. When using such competitive channelization codes at the same time, the signals of associated code channels are mixed such that they can no longer be separated in the receiver. Orthogonality is then lost.





Figure 4-1: Code tree of channelization codes

The domain of a certain channelization code is the outer branch range (with minimum symbol rate and max. spreading factor). It is based on the channelization code selected in the code tree. Using a spreading code means that its entire domain is used.

1. To access code domain graphic, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".

4. Select "Code Domain".




The graph indicates the code domain assignment of all active code channels.

The channelization code is plotted at the X axis, the colored bars indicate coherent code channels. The colors are assigned to the spreading factor, the allocation is shown below the graph. The relative power can be taken from the height of the bar.

4.11.4 Channel Graph

1. To access channel graph, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Channel Graph".



The channel graph dialog shows the active code channels.

The channel number is plotted on the X axis. The red bars represent the special channel (P-CCPCH1 to PDSCH in the downlink, P-CCPCH1 to PUSCH in the uplink), the green bars the data channels (DPCH). The height of the bars shows the relative power of the channel. The graph is calculated from the settings that have been made.

4.12 DPCCH Settings

The "Config DPCCH" dialog contains the parameters required for configuring the fields of the dedicated physical controller.

1. To access the DCCPH settings, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".
5. In the channel table, select "DPCCH Settings > Config..." for the respective channel.
6. Select "DPCCH Settings > Config..."

Data	Midamble	Data	Guard
44	144	44	16

Slot Format: 0 Midamble Shift: 120

TFCI	Sync Shift	TPC
Number of TFCI Bits		
TFCI Value		

The selected slot format predetermines the setting of the parameter provided in this dialog. Whenever the "TFCI State" and "Pilot Length" settings are changed, the slot format is adjusted accordingly. These parameters apply to the S-CCPCH channel.

4.12.1 Slot Structure and Slot Format

1. To access the DCCPH settings, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".
5. In the channel table, select "DPCCH Settings > Config..." for the respective channel.
6. Select "DPCCH Settings > Config..."

Data	Midamble	Data	Guard
44	144	44	16

Slot Format: 0 Midamble Shift: 120

TFCI Sync Shift TPC

Number of TFCI Bits: 0

TFCI Value: 0

The selected slot format predetermines the setting of the parameter provided in this dialog. Whenever the "TFCI State" and "Pilot Length" settings are changed, the slot format is adjusted accordingly. These parameters apply to the S-CCPCH channel.

Slot Structure

Displays the slot structure.

The structure in the graph represents the currently selected slot format.

Remote command:

n.a.

Slot Format

Displays the slot format.

The slot format display changes when the "Number of TFCI Bits" and the "Number of Sync Shift & TPC Bits" are modified.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:SFORmat on page 139

Midamble Shift

Displays the midamble shift.

The midamble can be shifted in the range of 0 to 120 chips in increments of 8 chips. Channels belonging to the same user equipment are characterized by the same midamble shift.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:MSHift? on page 138

4.12.2 TFCI Settings

1. To access the TFCI settings, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".
5. In the channel table, select "DPCCH Settings > Config..." for the respective channel.
6. Select "DPCCH Settings > Config... > TFCI"

This tab contains the parameters required for setting the TFCI length and value.

Number of TFCI Bits

Selects the length of the TFCI field expressed in bits.


Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:DPCCh:TFCI:LENGth on page 136

TFCI Value

Enters the value of the TFCI field. The value range is 0 to 1023.

The coded TFCI word is divided into four parts:



Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:DPCCh:TFCI:VALue on page 136

4.12.3 Sync Shift Settings

1. To access these settings, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".
5. In the channel table, select "DPCCH Settings > Config..." for the respective channel.
6. Select "DPCCH Settings > Config... > Sync Shift"

Data	Midamble	Data	Guard
44	144	44	16

Slot Format: 0 Midamble Shift: 120

TFCI	Sync Shift	TPC
Number of Sync Shift & TPC Bits: 0 & 0		
Sync Shift Pattern: 1...		
Sync Shift Repetition M: 1		

This tab contains the parameters required for setting the synchronization shift.

Number of Sync Shift & TPC Bits

Selects the length of the sync shift and the length of the TPC field expressed in bits. The available values depend on the slot format.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:DPCCh:SYNC:LENGth on page 135

Sync Shift Pattern

Enters the bit pattern for the sync shift. The maximum pattern length is 64 bits.

The following values are allowed:

- 0: decreases the sync shift

- 1: increases the sync shift
- -: the sync shift stays unchanged

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:DPCCh:SYNC:PATtern on page 135
```

Sync Shift Repetition M

Enters the value for the sync shift repetition. This value defines the spacing for the sync shift which is used to transmit a new timing adjustment. M specifies the spacing in subframes of 5 ms each.

Remote command:

```
[ :SOURce<hw> ] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:
CHANnel<us0>:DPCCh:SYNC:REPetition on page 135
```

4.12.4 E-UCCH Settings

1. To access the E-UCCH settings, select "TD-SCDMA > General > Link Direction > Uplink / Reverse".
2. In the "Cells" tab, select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".
5. In the channel table, select "Channel Type > E-PUCH 16 QAM " for the respective channel.
6. Select "DPCCH Settings > Config... > E-UCCH".

TD-SCDMA: Cell1/Slot1/DPCCH1/UL			
Data 88	Midamble 144	Data 88	Guard 16
Slot Format	1	Midamble Shift	120
E-UCCH		TPC	
Number Of E-UCCH Channels	0	Number Of Phy. Chan. Bits Per E-UCCH	32
(Bits 0..15 Mapped To E-UCCH Part 1 And Bits 16..31 Mapped To E-UCCH Part 2)			
E-TFCI Value	0	Retransmission Sequence Number	0
HARQ Process ID	0		

This tab contains the parameters for configuring this specific channel type in uplink transmission direction.

These settings are preconfigured and disabled, if an HSUPA coding type is enabled for the corresponding channel.

Number of E-UCCH Channels

Sets the number of the E-DCH Uplink Control Channels (E-UCCH).

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:CCOunt on page 132
```

Number of Phy. Chan. Bits per E-UCCH

Displays the number of physical channel bits per one E-UCCH.

The value is fixed to 32.

Remote command:

n.a.

E-TFCI Value

Enters the value of the TFCI field.

If an HSUPA is enabled for the corresponding channel, the E-TFCI value is set to the value configured for the parameter [Transport Block Size Index](#) .

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:TFCI on page 133
```

Retransmission Sequence Number (E-UCCH)

Sets the retransmission sequence number.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:RSNumber on page 133
```

HARQ Process ID

Sets the HARQ process ID.

Remote command:

```
[ :SOURCE<hw> ] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:HPID on page 133
```

4.12.5 TPC Settings

The "TPC" tab contains the parameters required for configuring the TPC field.

1. To access the TPC settings, select "TD-SCDMA > Cells".
2. Select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. Select "Common".

5. In the channel table, select "DPCCH Settings > Config... > TPC".

This tab contains the parameters for configuring the TPC field parameters. The selected "Link direction" determines the available parameters.

Number of Sync Shift & TPC Bits

Selects the length of the sync shift and the length of the TPC field expressed in bits. The available values depend on the slot format.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:SYNC:LENGth on page 135

Number of TPC Bits Per E-UCCH

Displays the number of the TPC field bits of the E-UCCH channel type, i.e. in uplink transmission direction.

Remote command:

n.a.

TPC Source

Selects the data source for the TPC field of the DPCCH.

The following standard data sources are available:

- "Pattern"
 - An internally generated sequence according to a bit pattern.
 - Use the "Pattern" box to define the bit pattern.
- "Data List/Select DList"
 - A binary data from a data list, internally or externally generated.
 - Select "Select DList" to access the standard "Select List" dialog.
 - Select the "Select Data List > navigate to the list file *.dm_iqd > Select" to select an existing data list.
 - Use the standard "File Manager" function to transfer external data lists to the instrument.

- Use the "New" and "Edit" functions to create internally new data list or to edit an existing one.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:

CHANnel<us0>:DPCCh:TPC:DATA on page 136

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:

CHANnel<us0>:DPCCh:TPC:DATA:PATtern on page 137

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:

CHANnel<us0>:DPCCh:TPC:DATA:DSElect on page 137

Read Out Mode

Defines TPC data usage.

The TPC bits are used to signal the increase or reduction in transmit power to the called station. For all read out modes, 1 bit is taken from the data stream for the TPC field for each slot. The bit is entered into the bitstream several times, depending on the symbol rate. The difference between the modes lies in the usage of the TPC bits.

The different modes can be used to set a specific output power and then let the power oscillate around this value. For example, if the power is the pattern 11111, the power can be varied with "Single + alt. 01" and "Single + alt. 10". Thus, power measurements can be carried out at quasi-constant power.

- "Continuous:"
The TPC bits are used cyclically.
- "Single + All 0"
The TPC bits are used once, and then the TPC sequence is continued with 0 bits.
- "Single + All 1"
The TPC bits are used once, and then the TPC sequence is continued with 1 bit.
- "Single + alt. 01"
The TPC bits are used once and then the TPC sequence is continued with 0 bits and 1 bit alternately. Bits as appended in multiples, depending on the symbol rate, for example, 00001111.
- "Single + alt. 10"
The TPC bits are used once and then the TPC sequence is continued with 1 bit and 0 bits alternately. Bits as appended in multiples, depending on by the symbol rate, for example, 11110000.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:


CHANnel<us0>:DPCCh:TPC:READ on page 137

4.13 Slot Mode PRACH Settings

For uplink transmission direction, the "TD-SCDMA-Cell/Slot../UL" dialog contains the parameters required for configuring the (physical random access channel) PRACH and the UpTS (uplink pilot timeslot).

4.13.1 Common Settings

1. To access the PRACH settings, select "TD-SCDMA > General > Link Direction > Uplink / Reverse"
2. In the "Cells" tab, select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. In the "Common" tab, select "Slot Mode > PRACH"



This dialog comprises the common PRACH settings.

Power Step

Enters the power by which the UpPTS is increased from repetition to repetition. The power set under Power is the "target power", used during the last repetition of the preamble.

Example:

UpPTS Power = 0 dB

UpPTS repetition = 3

Power step = 3

Generated power sequence:

Preamble 1 -6 dB	→ + 3 dB	Preamble 2 -3 dB	→ + 3 dB	Preamble 3 0 dB
---------------------	----------	---------------------	----------	--------------------

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:PSTep
on page 147

UpPTS Start

Enters the number of the subframe in which the first UpPTS has to be transmitted. The value range is 0 to 10.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:START`
on page 147

Distance UpPTS

Enters the value to vary the timing between UpPTS and RACH.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:DISTance`
on page 146

Sequence Length


Displays the value of the sequence length.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:SEnGth?`
on page 148

4.13.2 UpPTS Settings

1. To access these settings, select "TD-SCDMA > General > Link Direction > Uplink / Reverse"
2. In the "Cells" tab, select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. In the "Common" tab, select "Slot Mode > PRACH".
5. Select "UpPTS".



This dialog comprises the UpPTS settings.

Power

Enters the power of the UpPTS.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:POWer`
on page 146

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:PCORrection?`
on page 146

UpPTS Repetition

Enters the number of UpPTS repetitions before a PRACH burst happens.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:REPetition on page 147

4.13.3 RACH Message Part Settings

1. To access these settings, select "TD-SCDMA > General > Link Direction > Uplink / Reverse"
2. In the "Cells" tab, select "Cell 1...Cell 4".
3. In the "Slots" tab, select "Slot 0...Slot 6".
4. In the "Common" tab, select "Slot Mode > PRACH".
5. Select "RACH Message Part".

TD-SCDMA: Cell1/Slot1/UL	
<input checked="" type="radio"/> Common <input type="radio"/> UpPTS <input type="radio"/> RACH Message Part	
State	0
Message Length	1 Subframe (5 ms)
Slot Format	0
Power	0.00 dB
Spreading Factor	16
Spreading Code	1
Data Source	PN 9
Current User	1
Midamble Shift	120

This dialog comprises the RACH (random access channel) message part settings.

State (RACH Message Part)

Activates or deactivates the RACH (random access channel) message part.

Remote command:

[:SOURCE<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:STATE on page 145

Message Length

Selects the message length of the random access channel expressed in subframes.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:LENGth
on page 143

Slot Format (PRACH)

Displays the slot format of the PRACH. The slot format depends on the selected spreading factor.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFORmat?
on page 145

Power (RACH Message Part)

Enters the power of the PRACH message part.

The value range is -80 dB to 0 dB.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:POWer
on page 144
[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:
PCORrection on page 143

Spreading Factor (PRACH)

Selects the spreading factor for the PRACH.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFACtor
on page 144

Spreading Code (PRACH)

Enters the spreading code for the PRACH. The code channel is spread with the set spreading code. The range of values of the spreading code depends on the channel type and the spreading factor.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SCODE
on page 144

Data Source (PRACH)

Selects data source for the PRACH.

The following standard data sources are available:

- "All 0, All 1"
An internally generated sequence containing 0 data or 1 data.
- "PNxx"
An internally generated pseudo-random noise sequence.
- "Pattern"
An internally generated sequence according to a bit pattern.
Use the "Pattern" box to define the bit pattern.
- "Data List/Select DList"
A binary data from a data list, internally or externally generated.
Select "Select DList" to access the standard "Select List" dialog.

- Select the "Select Data List > navigate to the list file *.dm_iqd > Select" to select an existing data list.
- Use the "New" and "Edit" functions to create internally new data list or to edit an existing one.
- Use the standard "File Manager" function to transfer external data lists to the instrument.

See also:

- Section "Modulation Data" in the R&S SMW user manual.
- Section "File and Data Management" in the R&S SMW user manual.
- Section "Data List Editor" in the R&S SMW user manual

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA`
on page 142

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:`
`DSElect` on page 142

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:`
`PATtern` on page 143

Current User (PRACH)

Enters the number of current users.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:USER`
on page 145

Midamble Shift (PRACH)

Displays the value for the midamble shift.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:MSHift?`
on page 143

4.14 Filter / Clipping / ARB Settings

Access:


- ▶ Select "TD-SCDMA > General > Filter/Clipping/ARB Settings".

The dialog comprises the settings, necessary to configure the baseband filter, to enable clipping and adjust the sequence length of the arbitrary waveform component.

4.14.1 Filter Settings

Access:

- ▶ Select "Filter".



This dialog comprises the settings required for configuring the baseband filter.

Filter

Selects the baseband filter.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:FILTer:TYPE` on page 100

Rolloff Factor or BxT

Sets the filter parameter.

The filter parameter ("Roll off Factor" or "BxT") depends on the currently selected filter type. This parameter is preset to the default for each of the predefined filters.

Remote command:

`[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAMeter:APCO25` on page 100

`[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAMeter:COSine` on page 100

`[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAMeter:GAUSS` on page 101

`[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAMeter:PGAuss` on page 101

[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAmeter:RCOSine on page 102

[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAmeter:SPHase on page 102

Cutoff Frequency Factor

Sets the value for the cutoff frequency factor. The cutoff frequency of the filter can be adjusted to reach spectrum mask requirements.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAmeter:LPASs on page 101

[:SOURce<hw>] :BB:TDSCdma:FILTer:PARAmeter:LPASSEVM on page 101

Chip Rate Variation

Enters the chip rate.


Remote command:

[:SOURce<hw>] :BB:TDSCdma:CRATe:VARiation on page 93

4.14.2 Clipping Settings

Access:

- ▶ Select "Clipping".



This dialog comprises the settings required for configuring the clipping.

Clipping State

Switches baseband clipping on and off.

Baseband clipping is a simple and effective way of reducing the crest factor of the signal. Since clipping is done before filtering, the procedure does not influence the spectrum. The EVM however increases.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:CLIPping:STATE` on page 100

Clipping Level

Sets the limit for clipping.

This value indicates at what point the signal is clipped. It is specified as a percentage, relative to the highest level. 100% indicates that clipping does not take place.

Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:CLIPping:LEVel` on page 99

Clipping Mode

Selects the clipping method. The dialog displays a graphical illustration on how this two methods work.

- "Vector $| i + jq |$ "
The limit is related to the amplitude $| i + q |$. The I and Q components are mapped together, the angle is retained.
- "Scalar $| i | , | q |$ "
The limit is related to the absolute maximum of all the I and Q values $| i | + | q |$. The I and Q components are mapped separately, the angle changes.


Remote command:

`[:SOURCE<hw>] :BB:TDSCdma:CLIPping:MODE` on page 99

4.14.3 ARB Settings

Access:

- ▶ Select "ARB".



This dialog comprises the settings required for configuring the ARB.

Sequence Length ARB

Changes the sequence length of the arbitrary waveform component of the signal. This component is calculated in advance and output in the arbitrary waveform generator. It is added to the realtime signal components.

The maximum sequence length depends on the installed ARB memory size and the current chip rate.

In pure amplifier tests with several channels and no real time channels, it is possible to improve the statistical properties of the signal by increasing the sequence length.

Remote command:

[:SOURce<hw>] :BB:TDSCdma :SLENgth on page 102

4.15 Power Ramping

The "Power Ramping Settings" dialog contains the shape and time parameters required for configuring the baseband power ramp.

- ▶ To access these settings, select "TD-SCDMA > General > Power Ramping".

Power Ramp Control	
Ramp Function	Cosine
Ramp Time	2 Chips
Rise Delay	-2 Chips
Fall Delay	2 Chips
In Baseband Only	<input type="checkbox"/>

This dialog comprises the settings required for power ramping.

Ramp Function

Selects the form of the transmitted power, i.e. the shape of the rising and falling edges during power ramp control.

- "Linear" The transmitted power rises and falls linear fashion.
- "Cosine" The transmitted power rises and falls with a cosine-shaped edge, which causes a more favorable spectrum than the Linear setting.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:PRAMP:SHAPE on page 95

Ramp Time

Sets the power ramping rise time and fall time for a burst.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:PRAMp:TIME on page 95

Rise Delay

Sets the offset in the rising edge of the envelope at the start of a burst. A positive value causes a delay and a negative value causes an advance.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:PRAMp:RDELay on page 95

Fall Delay

Sets the offset in the falling edge of the envelope at the end of a burst. A positive value causes a delay and a negative value causes an advance.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:PRAMp:FDELay on page 95

In Baseband Only

Activates or deactivates power ramping for the baseband signals.

Remote command:

[:SOURce<hw>] :BB:TDSCdma:PRAMp:BBONLY on page 95

5 Remote-Control Commands

The following commands are required to perform signal generation with the TD-SCDMA options in a remote environment. We assume that the R&S SMW has already been set up for remote operation in a network as described in the R&S SMW documentation. A knowledge about the remote control operation and the SCPI command syntax are assumed.



Conventions used in SCPI command descriptions

For a description of the conventions used in the remote command descriptions, see section "Remote Control Commands" in the R&S SMW user manual.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
ENTity<ch>	1 to 4	entity in a multiple entity configuration with separate baseband sources ENTity3 4 require option R&S SMW-K76
SOURce<hw>	[1] to 4	available baseband signals only SOURce1 possible, if the keyword ENTity is used
OUTPut<ch>	1 to 3	available markers
CELL<st>	[1] 2 3 4	Cell
DTCH<ch>	1 to 7	
SLOT<ch0>	[0] to 6	Slot number
CHANnel<us0>	[0] to 21	Channel number



Using SCPI command aliases for advanced mode with multiple entities

You can address multiple entities configurations by using the SCPI commands starting with the keyword `SOURce` or the alias commands starting with the keyword `ENTity`.

Note that the meaning of the keyword `SOURce<hw>` changes in the second case.

For details, see section "SCPI Command Aliases for Advanced Mode with Multiple Entities" in the R&S SMW user manual.

The following commands specific to the TD-SCDMA are described here:

- [General Commands](#)..... 92
- [Filter/Clipping/ARB Settings](#)..... 99
- [Trigger Settings](#)..... 103
- [Marker Settings](#)..... 107
- [Clock Settings](#)..... 109
- [Predefined Settings](#)..... 109
- [Cell Settings](#)..... 111

- [Enhanced Channels of Cell 1](#)..... 115
- [Channel Settings](#)..... 131
- [HSDPA/HSUPA Settings](#)..... 148

5.1 General Commands

[:SOURce<hw>]:BB:TDSCdma:COPY:SOURce	92
[:SOURce<hw>]:BB:TDSCdma:COPY:DESTination	92
[:SOURce<hw>]:BB:TDSCdma:COPY:EXECute	93
[:SOURce<hw>]:BB:TDSCdma:CRATe?	93
[:SOURce<hw>]:BB:TDSCdma:CRATe:VARiation	93
[:SOURce<hw>]:BB:TDSCdma:LINK	94
[:SOURce<hw>]:BB:TDSCdma:POWer:ADJust	94
[:SOURce<hw>]:BB:TDSCdma:POWer[:TOTal]?	94
[:SOURce<hw>]:BB:TDSCdma:PRAMp:BBONly	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:FDELay	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:RDELay	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:SHAPE	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:TIME	95
[:SOURce<hw>]:BB:TDSCdma:PRESet	96
[:SOURce<hw>]:BB:TDSCdma:RESet	96
[:SOURce<hw>]:BB:TDSCdma:SETTing:CATalog?	96
[:SOURce<hw>]:BB:TDSCdma:SETTing:LOAD	97
[:SOURce<hw>]:BB:TDSCdma:SETTing:STORE	97
[:SOURce<hw>]:BB:TDSCdma:SETTing:TMODeL	97
[:SOURce<hw>]:BB:TDSCdma:SETTing:TMODeL:CATalog?	97
[:SOURce<hw>]:BB:TDSCdma:STATe	98
[:SOURce<hw>]:BB:TDSCdma:VERSion?	98
[:SOURce<hw>]:BB:TDSCdma:WAVEform:CREate	98

[:SOURce<hw>]:BB:TDSCdma:COPY:SOURce <Source>

Selects the cell whose settings are to be copied.

Parameters:

<Source> 1 | 2 | 3 | 4
 Range: 1 to 4
 *RST: 1 (Cell1)

Example: See [\[:SOURce<hw>\]:BB:TDSCdma:COPY:DESTination](#)
 on page 92

Manual operation: See "Copy Cell..." on page 29

[:SOURce<hw>]:BB:TDSCdma:COPY:DESTination <Destination>

Selects the cell whose settings are to be overwritten.

Parameters:

<Destination> 1 | 2 | 3 | 4
 Range: 1 to 4
 *RST: 2 (Cell2)

Example:

```
BB:TDSC:LINK DOWN
BB:TDSC:COPY:SOUR 1
BB:TDSC:COPY:DEST 4
BB:TDSC:COPY:EXEC
```

Manual operation: See "Copy Cell..." on page 29

[:SOURce<hw>]:BB:TDSCdma:COPY:EXECute

Starts the copy process. The dataset of the selected source cell is copied to the destination cell.

Example: See [:SOURce<hw>]:BB:TDSCdma:COPY:DESTination on page 92

Usage: Event

Manual operation: See "Copy Cell..." on page 29

[:SOURce<hw>]:BB:TDSCdma:CRATe?

Queries the system chip rate.

The output chip rate which determines the rate of the spread symbols as is used for signal output can be set with the command SOUR:BB:TDSC:CRAT:VAR.

Return values:

<CRate> R1M28
 *RST: R1M28

Example:

```
BB:TDSC:CRAT?
Response: R1M2
The system chip rate is 1.2288 Mcps.
```

Usage: Query only

Manual operation: See "Chip Rate" on page 19

[:SOURce<hw>]:BB:TDSCdma:CRATe:VARiation <Variation>

Sets the output chip rate.

The output chip rate changes the output clock and the modulation bandwidth, as well as the synchronization signals that are output. It does not affect the calculated chip sequence.

Parameters:

<Variation> float
 Range: 400 to 5E6
 Increment: 0.001
 *RST: 1280000
 Default unit: Hz (c/s)

Example:

BB:TDSC:CRAT:VAR 4086001
 sets the chip rate to 4.08 Mcps.

Manual operation: See "[Chip Rate Variation](#)" on page 86

[[:SOURce<hw>]:BB:TDSCdma:LINK <Link>

Defines the transmission direction.

Parameters:

<Link> FORWARD | DOWN | REVERSE | UP
 *RST: DOWN

Example:

BB:TDSC:LINK DOWN

Manual operation: See "[Link Direction](#)" on page 19

[[:SOURce<hw>]:BB:TDSCdma:POWER:ADJUST

The command sets the power of the active channels in such a way that the total power of the active channels is 0 dB. This will not change the power ratio among the individual channels.

Example:

BB:TDSC:POW:ADJ
 the total power of the active channels is set to 0 dB, the power ratio among the individual channels is unchanged.

Usage:

Event

Manual operation: See "[Adjust Total Power to 0dB](#)" on page 30

[[:SOURce<hw>]:BB:TDSCdma:POWER[:TOTAl]?

Queries the total power of the active channels. After "Power Adjust", this power corresponds to 0 dB.

Return values:

<Total> float
 Increment: 0.01

Example:

BB:TDSC:POW:TOT?
 queries the total power of the active channels.
 Response: -22.5
 the total power is -22.5 dB.

Usage:

Query only

Manual operation: See ["Total Power"](#) on page 30

[[:SOURce<hw>]:BB:TDSCdma:PRAMP:BBONLY <BbOnly>

Activates or deactivates power ramping for the baseband signals.

Parameters:

<BbOnly> 0 | 1 | OFF | ON
 *RST: 0

Example: BB:TDSC:PRAM:BBON ON

Manual operation: See [" In Baseband Only "](#) on page 90

[[:SOURce<hw>]:BB:TDSCdma:PRAMP:FDElay <FDElay>

[[:SOURce<hw>]:BB:TDSCdma:PRAMP:RDElay <RDElay>

Sets the offset in the falling edge of the envelope at the end of a burst. A positive value delays the ramp and a negative value causes an advance.

Parameters:

<RDElay> integer
 Range: -4 to 4
 *RST: 2 (FDElay) / -2 (RDElay)

Example: BB:TDSC:PRAM:RDEL 8.0
 Sets the offset in the rising edge of the envelope to 8.0 chips.

Manual operation: See [" Rise Delay "](#) on page 90

[[:SOURce<hw>]:BB:TDSCdma:PRAMP:SHAPE <Shape>

Selects the form of the transmitted power, i.e. the shape of the rising and falling edges during power ramp control.

Parameters:

<Shape> LINear | COSine
 *RST: COSine

Example: BB:TDSC:PRAM:SHAP LIN
 Sets a linear shape.

Manual operation: See [" Ramp Function "](#) on page 89

[[:SOURce<hw>]:BB:TDSCdma:PRAMP:TIME <Time>

Sets the power ramping rise time and fall time for a burst.

Parameters:

<Time> integer
 Range: 0 to 4
 *RST: 2

Example: BB:TDSC:PRAM:TIME 2.0

Manual operation: See "[Ramp Time](#)" on page 89

[:SOURce<hw>]:BB:TDSCdma:PRESet

Sets the parameters of the digital standard to their default values (*RST values specified for the commands).

Not affected is the state set with the command `SOURce<hw>:BB:TDSCdma:STATe`.

Example: SOURce1:BB:TDSCdma:PRESet

Usage: Event

Manual operation: See "[Set to Default](#)" on page 18

[:SOURce<hw>]:BB:TDSCdma:RESet

Resets all cells to the predefined settings. The reset applies to the selected link direction.

An overview is provided by table in [Set to Default](#).

Example: BB:TDSC:RES
resets all the cells to the predefined settings.

Usage: Event

Manual operation: See "[Reset All Cells](#)" on page 28

[:SOURce<hw>]:BB:TDSCdma:SETTing:CATalog?

Queries the files with settings in the default directory. Listed are files with the file extension *.tdscdma.

For general information on file handling in the default and in a specific directory, see section "MMEMory Subsystem" in the R&S SMW user manual.

Return values:

<Catalog> <filename1>,<filename2>,...
Returns a string of filenames separated by commas.

Example:

```
MMEM:CDIR '/var/user/tdscdma'
SOURce1:BB:TDSCdma:SETTing:CATalog?
// Response: "up", "down"
SOURce1:BB:TDSCdma:SETTing:LOAD "up"
SOURce1:BB:TDSCdma:SETTing:STOR 'tdscdma_1'
```

Usage: Query only

Manual operation: See "[Save/Recall](#)" on page 19

[:SOURce<hw>]:BB:TDSCdma:SETting:LOAD <Filename>

Loads the selected file from the default or the specified directory. Loaded are files with extension `*.tdscdma`.

Setting parameters:

<Filename> "<filename>"
Filename or complete file path; file extension can be omitted

Example: See [\[:SOURce<hw>\]:BB:TDSCdma:SETting:CATalog?](#)
on page 96

Usage: Setting only

Manual operation: See ["Save/Recall"](#) on page 19

[:SOURce<hw>]:BB:TDSCdma:SETting:STORe <Filename>

Stores the current settings into the selected file; the file extension (`*.tdscdma`) is assigned automatically.

Setting parameters:

<Filename> string
Filename or complete file path

Example: See [\[:SOURce<hw>\]:BB:TDSCdma:SETting:CATalog?](#)
on page 96

Usage: Setting only

Manual operation: See ["Save/Recall"](#) on page 19

[:SOURce<hw>]:BB:TDSCdma:SETting:TMODeI <TModel>

Selects the file with the test models defined in the TD-SCDMA standard or a self-defined test setup.

Parameters:

<TModel> string

Example: `BB:TDSC:SETT:TMOD 'Test_Mode_ACLR'`
calls the specified test model.

Manual operation: See ["Test Setups/Models"](#) on page 30

[:SOURce<hw>]:BB:TDSCdma:SETting:TMODeI:CATalog?

Queries the file with the test models defined in the TD-SCDMA standard or a self-defined test setup.

Return values:

<Catalog> <filename1>,<filename2>,...
Returns a string of filenames separated by commas.

Example:

```
MMEM:CDIR '/var/user/tdscdma'
SOURCE1:BB:TDSCdma:SETTING:TModel:CATalog?
// Response: "tdscma_tm1", "tdscma_tm2"
```

Usage: Query only

[:SOURCE<hw>]:BB:TDSCdma:STATE <State>

Activates the standard and deactivates all the other digital standards and digital modulation modes in the same path.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: SOURCE1:BB:TDSCdma:STATE ON

Manual operation: See "[State](#)" on page 18

[:SOURCE<hw>]:BB:TDSCdma:VERSION?

Queries the version of the TD-SCDMA standard underlying the definitions.

Return values:

<Version> string

Example: BB:TDSC:VERS?
Response: Release C

Usage: Query only

Manual operation: See "[TD-SCDMA Version](#)" on page 19

[:SOURCE<hw>]:BB:TDSCdma:WAVEform:CREate <Filename>

Stores the current settings as an ARB signal in a waveform file (*.wv).

For general information on file handling in the default and in a specific directory, see section "MMEMory Subsystem" in the R&S SMW operating manual.

Setting parameters:

<Filename> string
Filename or complete file path; file extension is assigned automatically

Example: MMEM:CDIR '/var/user/wavefrom'
SOURCE1:BB:TDSCdma:WAVEform:CREate "tdscdma"

Usage: Setting only

Manual operation: See "[Generate Waveform File](#)" on page 19

5.2 Filter/Clipping/ARB Settings

<code>[:SOURce<hw>]:BB:TDSCdma:CLIPping:LEVel</code>	99
<code>[:SOURce<hw>]:BB:TDSCdma:CLIPping:MODE</code>	99
<code>[:SOURce<hw>]:BB:TDSCdma:CLIPping:STATe</code>	100
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:TYPE</code>	100
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:APCO25</code>	100
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:COsine</code>	100
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:GAUSS</code>	101
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:LPASS</code>	101
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:LPASSEVM</code>	101
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:PGAuss</code>	101
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:RCOSine</code>	102
<code>[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:SPHase</code>	102
<code>[:SOURce<hw>]:BB:TDSCdma:SLenGth</code>	102

`[:SOURce<hw>]:BB:TDSCdma:CLIPping:LEVel <Level>`

Sets the limit for clipping.

This value indicates at what point the signal is clipped. It is specified as a percentage, relative to the highest level. 100% indicates that clipping does not take place.

Parameters:

`<Level>` integer
 Range: 1 to 100
 *RST: 100
 Default unit: PCT

Example: `BB:TDSC:CLIP:LEV 80`
`BB:TDSC:CLIP:STAT ON`

Manual operation: See "[Clipping Level](#)" on page 87

`[:SOURce<hw>]:BB:TDSCdma:CLIPping:MODE <Mode>`

Sets the method for level clipping.

Parameters:

`<Mode>` VECTor | SCALar
VECTor
 The reference level is the amplitude.
SCALar
 The reference level is the absolute maximum of the I and Q values.
 *RST: VECTor

Example: `BB:TDSC:CLIP:MODE VECT`

Manual operation: See "[Clipping Mode](#)" on page 87

[:SOURce<hw>]:BB:TDSCdma:CLIPping:STATe <State>

Activates level clipping

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: BB:TDSC:CLIP:STAT ON

Manual operation: See "[Clipping State](#)" on page 87

[:SOURce<hw>]:BB:TDSCdma:FILTer:TYPE <Type>

Selects the filter type.

Parameters:

<Type> RCOSine | COSine | GAUSs | LGAuss | CONE | COF705 |
 COEqualizer | COFequalizer | C2K3x | APCO25 | SPHase |
 RECTangle | PGAuss | LPASs | DIRac | ENPShape |
 EWPSshape | LPASSEVM
 *RST: RCOSine

Example: BB:TDSC:FILT:TYPE RCOS

Manual operation: See "[Filter](#)" on page 85

[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:APCO25 <Apco25>

Sets the rolloff factor for filter type APCO25.

Parameters:

<Apco25> float
 Range: 0.05 to 0.99
 Increment: 0.01
 *RST: 0.2

Example: BB:TDSC:FILT:PAR:APCO25 0.2

Manual operation: See "[Rolloff Factor or BxT](#)" on page 85

[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:COSine <Cosine>

Sets the rolloff factor for the cosine filter type.

Parameters:

<Cosine> float
 Range: 0 to 1
 Increment: 0.01
 *RST: 0.35

Example: BB:TDSC:FILT:PAR:COS 0.35

Manual operation: See "[Rolloff Factor or BxT](#)" on page 85

[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:GAUSSs <Gauss>

Sets the BxT for the gauss filter type.

Parameters:

<Gauss>	float
	Range: 0.15 to 2.5
	Increment: 0.01
	*RST: 0.5

Example: BB:TDSC:FILT:PAR:GAUS 0.5

Manual operation: See "[Rolloff Factor or BxT](#)" on page 85

[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:LPASSs <LPass>

Sets the cutoff frequency factor for the Lowpass (ACP opt) filter type.

Parameters:

<LPass>	float
	Range: 0.05 to 2
	Increment: 0.01
	*RST: 0.5

Example: BB:TDSC:FILT:PAR:LPAS 0.5

Manual operation: See "[Cutoff Frequency Factor](#)" on page 86

[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:LPASSEVM <LPassEvm>

Sets the cutoff frequency factor for the Lowpass (EVM opt) filter type.

Parameters:

<LPassEvm>	float
	Range: 0.05 to 2
	Increment: 0.01
	*RST: 0.5

Example: BB:TDSC:FILT:PAR:LPASSEVM 0.5

Manual operation: See "[Cutoff Frequency Factor](#)" on page 86

[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:PGAUSSs <PGauss>

Sets the BxT for the pure gauss filter type.

Parameters:

<PGauss>	float
	Range: 0.15 to 2.5
	Increment: 0.01
	*RST: 0.5

Example: BB:TDSC:FILT:PAR:GAUS 0.5

Manual operation: See ["Rolloff Factor or BxT"](#) on page 85

[[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:RCOSine <RCosine>

Sets the rolloff factor for the root cosine filter type.

Parameters:

<RCosine> float
 Range: 0 to 1
 Increment: 0.01
 *RST: 0.22

Example: BB:TDSC:FILT:PAR:RCOS 0.22

Manual operation: See ["Rolloff Factor or BxT"](#) on page 85

[[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:SPHase <SPHase>

Sets the BxT for the split phase filter type.

Parameters:

<SPHase> float
 Range: 0.15 to 2.5
 Increment: 0.01
 *RST: 2

Example: BB:TDSC:FILT:PAR:SPH 0.5

Manual operation: See ["Rolloff Factor or BxT"](#) on page 85

[[:SOURce<hw>]:BB:TDSCdma:SLENgth <SLength>

Sets the sequence length of the arbitrary waveform component of the TD-SCDMA signal in the number of frames. This component is calculated in advance and output in the arbitrary waveform generator. It is added to the realtime signal components.

Parameters:

<SLength> integer
 Range: 1 to 5000
 *RST: 1

Example: BB:TDSC:SLEN 10

Manual operation: See ["Sequence Length ARB"](#) on page 88

5.3 Trigger Settings

Example: Trigger configuration

```

SOURcel:BB:TDSCdma:TRIGger:SOURce INTernal
SOURcel:BB:TDSCdma:TRIGger:SEQuence ARETrigger
SOURcel:BB:TDSCdma:STAT ON
SOURcel:BB:TDSCdma:TRIGger:EXECute
SOURcel:BB:TDSCdma:TRIGger:ARM:EXECute
SOURcel:BB:TDSCdma:TRIGger:RMODe?
// stopped
SOURcel:BB:TDSCdma:TRIGger:EXECute
SOURcel:BB:TDSCdma:TRIGger:RMODe?
// run

// SOURcel:BB:TDSCdma:TRIGger:SEQuence SING
// SOURcel:BB:TDSCdma:TRIGger:SLUNit SEQuence
// SOURcel:BB:TDSCdma:TRIGger:SLENgth 2

// SOURcel:BB:TDSCdma:TRIGger:SEQuence ARET
// SOURcel:BB:TDSCdma:TRIGger:SOURce EGT1
// SOURcel:BB:TDSCdma:TRIGger:EXTErnal:SYNChronize:OUTPut 1
// SOURcel:BB:TDSCdma:TRIGger:EXTErnal:INHibit 100
// SOURcel:BB:TDSCdma:TRIGger:EXTErnal:DELay 10

```

[:SOURce<hw>]:BB:TDSCdma:TRIGger:ARM:EXECute.....	103
[:SOURce<hw>]:BB:TDSCdma:TRIGger:EXECute.....	103
[:SOURce<hw>]:BB:TDSCdma:TRIGger:EXTErnal:SYNChronize:OUTPut.....	104
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OBASeband:DELay.....	104
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OBASeband:INHibit.....	104
[:SOURce<hw>]:BB:TDSCdma:TRIGger:RMODe?.....	104
[:SOURce<hw>]:BB:TDSCdma:TRIGger:SLENgth.....	105
[:SOURce<hw>]:BB:TDSCdma:TRIGger:SLUNit.....	105
[:SOURce<hw>]:BB:TDSCdma:TRIGger:SOURce.....	105
[:SOURce<hw>]:BB:TDSCdma:TRIGger[:EXTErnal]:DELay.....	106
[:SOURce<hw>]:BB:TDSCdma:TRIGger[:EXTErnal]:INHibit.....	106
[:SOURce<hw>]:BB:TDSCdma[:TRIGger]:SEQuence.....	106

[:SOURce<hw>]:BB:TDSCdma:TRIGger:ARM:EXECute

Stops signal generation; a subsequent trigger event restarts signal generation.

Example: See [Example "Trigger configuration"](#) on page 103

Usage: Event

Manual operation: See ["Arm"](#) on page 22

[:SOURce<hw>]:BB:TDSCdma:TRIGger:EXECute

Executes a trigger.

Example: See [Example "Trigger configuration"](#) on page 103

Usage: Event

Manual operation: See ["Execute Trigger"](#) on page 22

[:SOURce<hw>]:BB:TDSCdma:TRIGger:EXtErnal:SYNChronize:OUTPut <Output>

Enables signal output synchronous to the trigger event.

Parameters:

<Output> 0 | 1 | OFF | ON

*RST: 1

Example: See [Example "Trigger configuration"](#) on page 103

Manual operation: See ["Sync. Output to External Trigger/Sync. Output to Trigger"](#) on page 23

[:SOURce<hw>]:BB:TDSCdma:TRIGger:OBASeband:DELay <Delay>

Specifies the trigger delay for triggering by the trigger signal from the other baseband.

Parameters:

<Delay> float

Range: 0 to 2147483647

Increment: 0.01

*RST: 0

Example:

SOURce1:BB:TDSCdma:TRIGger:SOURce INTB

SOURce1:BB:TDSCdma:TRIGger:OBASeband:DELay 100

SOURce1:BB:TDSCdma:TRIGger:OBASeband:INHibit 10

Manual operation: See ["Trigger Delay"](#) on page 24

[:SOURce<hw>]:BB:TDSCdma:TRIGger:OBASeband:INHibit <Inhibit>

For triggering via the other path, specifies the duration by which a restart is inhibited.

Parameters:

<Inhibit> integer

Range: 0 to 67108863

*RST: 0

Example: See [\[:SOURce<hw>\]:BB:TDSCdma:TRIGger:EXtErnal:SYNChronize:OUTPut](#) on page 104

Manual operation: See ["External Trigger Inhibit"](#) on page 24

[:SOURce<hw>]:BB:TDSCdma:TRIGger:RMODe?

Queries the signal generation status.

Return values:

<RMode> STOP | RUN

Example: See [Example "Trigger configuration"](#) on page 103

Usage: Query only

Manual operation: See ["Running/Stopped"](#) on page 22

[:SOURce<hw>]:BB:TDSCdma:TRIGger:SLENgth <SLength>

Defines the length of the signal sequence that is output in the `SINGLE` trigger mode.

Parameters:

<SLength>	integer
Range:	1 to max
*RST:	12800

Example: See [Example "Trigger configuration"](#) on page 103

Manual operation: See ["Trigger Signal Duration"](#) on page 22

[:SOURce<hw>]:BB:TDSCdma:TRIGger:SLUNit <SIUnit>

Defines the unit for the entry of the signal sequence length.

Parameters:

<SIUnit>	FRAMe CHIP SEQuence
*RST:	SEQuence

Example: See [Example "Trigger configuration"](#) on page 103

Manual operation: See ["Signal Duration Unit"](#) on page 22

[:SOURce<hw>]:BB:TDSCdma:TRIGger:SOURce <Source>

Selects the trigger signal source and determines the way the triggering is executed. Provided are:

- Internal triggering by a command (`INTernal`)
- External trigger signal via one of the local or global connectors
 - `EGT1` | `EGT2`: External global trigger
 - `EGC1` | `EGC2`: External global clock
 - `ELTRigger`: External local trigger
 - `ELCLock`: External local clock
- Internal triggering by a signal from the other basebands (`INTA` | `INTB`)
- In master-slave mode, the external baseband synchronization signal (`BBSY`)
- `OBASeband` | `BEXTernal` | `EXTernal`: **Setting only**
 Provided only for backward compatibility with other Rohde & Schwarz signal generators.
 The R&S SMW accepts these values and maps them automatically as follows:

EXternal = EGT1, BEXternal = EGT2, OBASeband = INTA or INTB
(depending on the current baseband)

Parameters:

<Source> INTB|INTernal|OBASeband|EGT1|EGT2|EGC1|EGC2|ELTRigger|INTA|ELCLock|BEXternal|EXternal | BBSY
*RST: INTernal

Example: See [Example "Trigger configuration"](#) on page 103

Options: ELTRigger|ELCLock require R&S SMW-B10
BBSY require R&S SMW-B9

Manual operation: See ["Trigger Source"](#) on page 23

[[:SOURce<hw>]:BB:TDSCdma:TRIGger[:EXternal]:DELay <Delay>

Sets the trigger delay.

Parameters:

<Delay> float
Range: 0 to 2147483647
Increment: 0.01
*RST: 0
Default unit: samples

Example: See [Example "Trigger configuration"](#) on page 103

Manual operation: See ["Trigger Delay"](#) on page 24

[[:SOURce<hw>]:BB:TDSCdma:TRIGger[:EXternal]:INHibit <Inhibit>

Specifies the duration by which a restart is inhibited.

Parameters:

<Inhibit> integer
Range: 0 to 21.47*chipRate
*RST: 0

Example: See [Example "Trigger configuration"](#) on page 103

Manual operation: See ["External Trigger Inhibit"](#) on page 24

[[:SOURce<hw>]:BB:TDSCdma[:TRIGger]:SEQuence <Sequence>

Selects the trigger mode:

- AUTO = auto
- RETRigger = retrigger
- AAUTO = armed auto
- ARETRigger = armed retrigger
- SINGLE = single

Parameters:

<Sequence> AUTO | RETRigger | AAUTo | ARETrigger | SINGLE
 *RST: AUTO

Example: See [Example "Trigger configuration"](#) on page 103

Manual operation: See ["Trigger Mode"](#) on page 21

5.4 Marker Settings

Example: Marker configuration

```
SOURcel:BB:TDSCdma:TRIGger:OUTPut1:MODE USER
SOURcel:BB:TDSCdma:TRIGger:OUTPut1:PERiod 12800
```

```
SOURcel:BB:TDSCdma:TRIGger:OUTPut1:MODE RAT
SOURcel:BB:TDSCdma:TRIGger:OUTPut1:ONTime 1
SOURcel:BB:TDSCdma:TRIGger:OUTPut1:OFFTime 1
// defines the on/off ratio
```

```
// Marker delay configuration
SOURcel:BB:TDSCdma:TRIGger:OUTPut1:DELay 1600
// delays the marker signal output
```

[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:MODE	107
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:ONTime	108
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:OFFTime	108
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:PERiod	108
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:DELay	108

[\[:SOURce<hw>\]:BB:TDSCdma:TRIGger:OUTPut<ch>:MODE <Mode>](#)

Defines the signal for the selected marker output.

Parameters:

<Mode> RFRame | SFNR | CSPeriod | RATio | USER | FACTive
 RFRame = Radio Frame
 SFNR = System Frame Number (SFN) Restart
 CSPeriod = Chip Sequence Period (ARB)
 RATio = On/Off Ratio
 USER = User Period
 *RST: RFRame

Example: See [Example "Marker configuration"](#) on page 107

Manual operation: See ["Marker Mode"](#) on page 25

```
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:ONTime <OnTime>
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:OFFTime <OffTime>
```

Sets the number of chips during which the marker output is on or off.

*) If R&S SMW-B9 is installed, the minimum marker duration depends on the sample/symbol rate.

See chapter "Basics on ..." in the R&S SMW user manual.

Parameters:

```
<OffTime>          integer
                   Range:    1 (R&S SMW-B10) / 1* (R&S SMW-B9) to
                               16777215
                   *RST:    1
```

Example: See [Example "Marker configuration"](#) on page 107

Manual operation: See ["Marker Mode"](#) on page 25

```
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:PERiod <Period>
```

Sets the repetition rate for the signal at the marker outputs.

*) If R&S SMW-B9 is installed, the minimum marker duration depends on the sample/symbol rate.

See chapter "Basics on ..." in the R&S SMW user manual.

Parameters:

```
<Period>          integer
                   Range:    1 (R&S SMW-B10) / 1* (R&S SMW-B9) to
                               (2^32-1) chips
                   *RST:    12800
```

Example: See [Example "Marker configuration"](#) on page 107

Manual operation: See ["Marker Mode"](#) on page 25

```
[:SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:DELay <Delay>
```

Defines the delay between the signal on the marker outputs and the start of the signals.

Parameters:

```
<Delay>          float
                   Range:    0 to 16777215
                   Increment: 0.001
                   *RST:    0
```

Example: See [Example "Marker configuration"](#) on page 107

Manual operation: See ["Marker x Delay"](#) on page 26

5.5 Clock Settings

[:SOURce<hw>]:BB:TDSCdma:CLOCK:MODE.....	109
[:SOURce<hw>]:BB:TDSCdma:CLOCK:SOURce.....	109

[:SOURce<hw>]:BB:TDSCdma:CLOCK:MODE <Mode>

Sets the type of externally supplied clock.

Parameters:

<Mode> CHIP
 *RST: CHIP

Example: SOURce1:BB:TDSCdma:CLOCK:MODE CHIP
 Sets the type of externally supplied clock.

Options: R&S SMW-B10

Manual operation: See "[Clock Mode](#)" on page 27

[:SOURce<hw>]:BB:TDSCdma:CLOCK:SOURce <Source>

Selects the clock source:

- INTernal: Internal clock reference
- ELCLock: External local clock
- EXTernal = ELCLock: Setting only
 Provided for backward compatibility with other Rohde & Schwarz signal generators

Parameters:

<Source> INTernal|ELCLock|EXTernal
 *RST: INTernal

Example: BB:TDSC:CLOC:SOUR INT
 Selects an internal clock reference.

Options: ELCLock requires R&S SMW-B10

Manual operation: See "[Clock Source](#)" on page 27

5.6 Predefined Settings

[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:DPCH:COUNT.....	109
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:DPCH:CRESt.....	110
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:DPCH:SFACTOR.....	110
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:EXECute.....	111
[:SOURce<hw>]:BB:TDSCdma:DOWN:PPARAmeter:PCCPch:STATe.....	111

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:PPARAmeter:DPCH:COUNT <Count>

Sets the number of activated DPCHs.

The maximum number depends on the spreading factor:

Max. No. DPCH = 3 x "Spreading Factor"

Parameters:

<Count> integer
 Range: 1 to 48
 *RST: 12

Example: BB:TDSC:DOWN:PPAR:DPCH:COUN 48

Manual operation: See ["Number of Dedicated Channels"](#) on page 32

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:PPARameter:DPCH:CRESt <Crest>

Selects the desired range for the crest factor of the test scenario.

Parameters:

<Crest> MINimum | AVERage | WORSt

MINimum

The crest factor is minimized.

The channelization codes are distributed uniformly over the code domain. The timing offsets are increased by 3 per channel.

AVERage

An average crest factor is set.

The channelization codes are distributed uniformly over the code domain. The timing offsets are all set to 0.

WORSt

The crest factor is set to an unfavorable value (i.e. maximum).

The channelization codes are assigned in ascending order. The timing offsets are all set to 0.

*RST: MINimum

Example: BB:TDSC:DOWN:PPAR:DPCH:CRES WORS

Manual operation: See ["Crest Factor"](#) on page 32

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:PPARameter:DPCH:SFActor <SFactor>

Sets the spreading factor for the DPCHs.

Parameters:

<SFactor> 1 | 2 | 4 | 8 | 16
 *RST: 16

Example: BB:TDSC:DOWN | UP:PPAR:DPCH:SFAC 16

Manual operation: See ["Spreading Factor Dedicated Channels"](#) on page 32

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:PPARmeter:EXECute

Presets the channel table of cell 1 with the parameters defined by the PPARmeter commands. Scrambling Code 0 is automatically selected.

Example: BB:TDSC:DOWN:PPAR:EXEC

Usage: Event

Manual operation: See "Accept" on page 32

[:SOURce<hw>]:BB:TDSCdma:DOWN:PPARmeter:PCCPch:STATe <State>

Defines, if P-CCPCH is used in the scenario or not.

If P-CCPCH is used, both P-CCPCHs are activated in slot 0 with spreading code 0+1.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 1

Example: BB:TDSC:DOWN:PPAR:PCCP:STAT ON

Manual operation: See "Use PCCPCH (Downlink Slot 0, code 0+1)" on page 31

5.7 Cell Settings

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:MODE.....	111
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:MODE.....	111
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:POWer.....	112
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:POWer.....	112
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:STATe?.....	112
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:STATe?.....	112
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:MCODe?.....	112
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:PROTation.....	113
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SCODE.....	113
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SCODE:STATe.....	113
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SDCode?.....	113
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SPOint.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:STATe.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SUCode.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:TDELay.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:USERS.....	115

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:MODE**[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:MODE <Mode>**

Selects whether to use the pilot time slot and its power or not.

Parameters:

<Mode> AUTO | ON | OFF
 *RST: AUTO

Example: BB:TDSC:DOWN:CELL1:DWPT:MODE ON

Manual operation: See "[DwPTS Mode/ UpPTS Mode](#)" on page 34

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:POWer
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:POWer <Power>

Sets the power of the downlink/uplink pilot time slot.

Parameters:

<Power> float
 Range: -80 to 10
 Increment: 0.01
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:DWPT:POW -12.5
 sets the power of the downlink pilot slot.

Manual operation: See "[DwPTS Power/ UpPTS Power](#)" on page 34

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:STATe?
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:STATe?

Queries the state of the downlink/uplink pilot timeslot.

Return values:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example: BB:TDSC:DOWN:CELL1:DWPT:STAT?

Usage: Query only

Manual operation: See "[DwPTS Mode/ UpPTS Mode](#)" on page 34

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:MCODe?

Queries the basic midamble code id. The value is set automatically by the change of the scrambling code parameter (it is equal to scrambling code).

Return values:

<MCode> integer
 Range: 0 to 127
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:SCOD 15

Usage: Query only

Manual operation: See "[Basic Midamble Code ID](#)" on page 33

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:PROTation <PRotation>

Selects the phase rotation for the downlink pilots.

Parameters:

<PRotation> AUTO | S1 | S2

AUTO

Default phase rotation sequence according to the presence of the P-CCPCH.

S1

There is a P-CCPCH in the next four subframes.

S2

There is no P-CCPCH in the next four subframes.

*RST: AUTO

Example: BB:TDSC:DOWN:CELL1:PROT AUTO

Manual operation: See "[Phase Rotation](#)" on page 34

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SCODE <SCode>

Sets the scrambling code. The scrambling code is used for transmitter-dependent scrambling of the chip sequence.

Parameters:

<SCode> integer

Range: 0 to 127

*RST: 0

Example: BB:TDSC:DOWN:CELL1:SCOD 15
sets the scrambling code for cell 1.

Manual operation: See "[Scrambling Code](#)" on page 33

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SCODE:STATe <State>

Activates or deactivates the scrambling code.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 1

Example: BB:TDSC:DOWN:CELL1:SCOD:STAT ON

Manual operation: See "[Use \(Scrambling Code\)](#)" on page 33

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SDCode?

Queries the SYNC-DL code.

Return values:

<SdCode> integer
 Range: 0 to 31
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:SDC?

Usage: Query only

Manual operation: See "[SYNC-DL Code](#)" on page 34

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SPOINT <SPoint>

Sets the switching point between the uplink slots and the downlink slots in the frame.

Parameters:

<SPoint> integer
 Range: 1 to 6
 *RST: 3

Example: BB:TDSC:DOWN:CELL1:SPO 4

Manual operation: See "[Switching Point](#)" on page 36

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:STATE <State>

Activates and deactivates the specified cell.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:STAT ON

Manual operation: See "[Cell On / Cell Off](#)" on page 31

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SUCODE <SuCode>

Sets the SYNC-UL code.

Parameters:

<SuCode> integer
 Range: 0 to 255
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:SUC 120

Manual operation: See "[SYNC-UL Code](#)" on page 34

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:TDELAY <TDelay>

Sets the time shift of the selected cell compared to cell 1; the time delay of cell 1 is 0.

Parameters:

<TDelay> integer
 Range: 0 to 19200
 *RST: 0
 Default unit: chip

Example:

BB:TDSC:DOWN:CELL2:TDEL 100
 'shifts cell 2 by 100 chips compared to cell 1.

Manual operation: See "Time Delay" on page 35

[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:USERS <Users>

Sets the total number of users of the cell.

Parameters:

<Users> 2 | 4 | 6 | 8 | 10 | 12 | 14 | 16
 *RST: 16

Example:

BB:TDSC:DOWN:CELL1:USER 4

Manual operation: See "Number of Users" on page 35

5.8 Enhanced Channels of Cell 1

[[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:SSPattern.....	116
[[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TPCPattern.....	117
[[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TTInterval?.....	117
[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:ANPattern.....	117
[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:CQI:MODulation.....	118
[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:CQI:VALue.....	118
[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:TTInterval?.....	118
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BIT:LAYer.....	118
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BIT:RATE.....	119
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BIT:STATE.....	119
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BLOCK:RATE.....	119
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BLOCK:STATE.....	119
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BPFRame?.....	120
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:CCOunt.....	120
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH: CRCSize.....	120
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:DATA....	121
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH: DATA:DSElect.....	121
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH: DATA:PATtern.....	122
[[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH: EPRotectioN.....	122
[[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:IONE.....	122

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:ITWO.....	122
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:IONE....	123
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:ITWO...	123
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH: RMATtribute.....	123
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:STATE...	123
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH: TBCount.....	123
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:TBSize..	124
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH: TTInterval.....	124
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:RUPLayer?.....	124
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:SCSMODE.....	125
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:SFORmat?.....	125
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:SLOTstate<ch>.....	125
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:STATE.....	125
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:TSCOUNT.....	126
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:TYPE.....	126
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:BPFRame?.....	126
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:CRCSIZE?.....	126
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA.....	127
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:DSElect.....	127
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:PATtern.....	128
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:EPROtection?.....	128
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:RMATtribute?.....	128
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:STATE.....	129
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBCOUNT?.....	129
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBSIZE?.....	129
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TTInterval?.....	129
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SCSMODE?.....	129
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SFORmat?.....	130
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SLOTstate<ch0>?.....	130
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:STATE.....	130
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:TYPE?.....	131

**[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:SSPattern
<SsPattern>, <BitCount>**

Sets the sync shift pattern and the pattern length.

Parameters:

<SsPattern>	numeric
	*RST: #H0
<BitCount>	integer
	Range: 1 to 21
	*RST: 3

Example:

BB:TDSC:DOWN:CELL1:ENH:DCH:PLCC:SSP #HA5,8
sets the sync shift pattern.

Manual operation: See "[Sync Shift Pattern](#)" on page 48

**[[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TPCPattern
<TpcPattern>, <BitCount>**

Sets the TPC pattern and the pattern length.

Parameters:

<TpcPattern> numeric
 *RST: #H0

<BitCount> integer
 Range: 1 to 21
 *RST: 3

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:PLCC:TPCP #HA5,8
 sets the TPC pattern

Manual operation: See "[TPC Pattern](#)" on page 48

[[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TTInterval?

Queries the transmission time interval.

Return values:

<TtInterval> 5MS | 10MS | 20MS | 40MS | 80MS

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:PLCC:TTIN?
 queries the TTI value
 Response: 5ms

Usage: Query only

Manual operation: See "[Transmission Time Interval \(TTI\)](#)" on page 48

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSIC:ANPattern
<AnPattern>, <BitCount>**

Sets the ACK/NACK Pattern and the maximum pattern length. A "1" corresponds to ACK, a "0" to NAK.

Parameters:

<AnPattern> numeric
 *RST: #H7

<BitCount> integer
 Range: 1 to 36
 *RST: 3

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSIC:ANP #HAA,8
 sets the ACK/NACK pattern

Manual operation: See "[ACK/NAK Pattern](#)" on page 50

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSIC:HQI:MODulation
<Modulation>**

Sets the CQI modulation.

Parameters:

<Modulation> QPSK | QAM16 | QAM64
*RST: QPSK

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSIC:HQI:MOD QAM16
sets the CQI modulation

Manual operation: See "[CQI Modulation](#)" on page 49

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSIC:HQI:VALue
<Value>**

Sets the CQI value.

Parameters:

<Value> integer
Range: 0 to 63
*RST: 0

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSIC:HQI:VAL 10
sets the CQI value

Manual operation: See "[CQI Value](#)" on page 49

[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSIC:TTINterval?

Queries the transmission time interval.

Return values:

<TtInterval> 5MS | 10MS | 20MS | 40MS | 80MS

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSIC:TTIN?
Response: 5ms

Usage: Query only

Manual operation: See "[Transmission Time Interval \(TTI\) – RMC HS-SICH](#)"
on page 49

[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:BIT:LAYer <Layer>

Sets the layer in the coding process at which bit errors are inserted.

Parameters:

<Layer> TRANsport | PHYSical
*RST: TRANsport

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:BIT:LAY TRAN

Manual operation: See ["Insert Errors On"](#) on page 51

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:BIT:RATE <Rate>

Sets the bit error rate.

Parameters:

<Rate> float
 Range: 1E-7 to 0.5
 Increment: 1E-7
 *RST: 0.001

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:BIT:RATE 5E-1
 sets the bit error rate.

Manual operation: See ["Bit Error Rate"](#) on page 51

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:BIT:STATE <State>

Activates or deactivates bit error generation.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:BIT:STAT ON

Manual operation: See ["State \(Bit Error\)"](#) on page 50

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:BLOCK:RATE <Rate>

Sets the block error rate.

Parameters:

<Rate> float
 Range: 1E-4 to 0.5
 Increment: 1E-4
 *RST: 0.1

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:BLOC:RATE 10E-1
 sets the block error rate.

Manual operation: See ["Block Error Rate"](#) on page 51

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:BLOCK:STATE <State>

Activates or deactivates block error generation.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

BB:TDSC:DOWN:CELL1:ENH:DCH:BLOC:STAT ON

Manual operation: See ["State \(Block Error\)"](#) on page 51

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:BPFRame?

Queries the data bits in the DPDCH component of the DPCH frame at physical level. The value depends on the slot format.

Return values:

<BpFrame> string

Example:

BB:TDSC:DOWN:CELL1:ENH:DCH:BPFR?

Usage:

Query only

Manual operation: See ["Data Bits Per Frame \(10 ms\)"](#) on page 44

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:CCOUNT <CCOUNT>

Sets the number of channels to be used.

The number of timeslots is set with the command

BB:TDSC:DOWN|UP:CELL1:ENH:DCH:TSCOUNT.

Parameters:

<CCOUNT> integer
 Range: 1 to 16
 *RST: 1(uplink), 2(downlink)

Example:

BB:TDSC:DOWN:CELL1:ENH:DCH:CCO 2

Manual operation: See ["Number of Channels \(DCH\)"](#) on page 43

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:CRCSIZE <CRCSIZE>

Sets the type (length) of the CRC.

Parameters:

<CRCSIZE> NONE | 8 | 12 | 16 | 24
 *RST: 16(DTCH), 12(DCCH)

Example:

BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:CRCS?
 queries the type (length) of the CRC.

Manual operation: See ["Size Of CRC"](#) on page 46

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
  DATA <Data>
```

The command selects the data source for the specified channel.

For the traffic channels, this value is specific for the selected radio configuration.

Parameters:

<Data>

PN9 | PN11 | PN15 | PN16 | PN20 | PN21 | PN23 | DLISt |
ZERO | ONE | PATtern

PNxx

PRBS data as per CCITT with period lengths between 29-1 and 223-1 is generated internally.

DLISt

Internal data from a programmable data list is used. The data list can be generated by the Data Editor or generated externally. Data lists are selected in the "Select Data List" field. The data list is selected with the command

```
BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA:DSEL <data
list name>.
```

ZERO | ONE

Internal 0 and 1 data is used.

PATtern

A user-definable bit pattern with a maximum length of 64 bits is generated internally. The bit pattern is defined in the "Pattern entry field". The bit pattern is selected with the command

```
BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA:PATT <bit
pattern>.
```

```
*RST:      PN9
```

Example:

```
BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:DATA PN9
selects PN9 as the data source of the transport channel.
```

Manual operation: See "[Data Source](#)" on page 45

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
  DATA:DSElect <DSelect>
```

Selects an existing data list file from the default directory or from the specific directory.

For general information on file handling in the default and in a specific directory, see section "MMEMory Subsystem" in the R&S SMWuser manual.

For the traffic channels, this value is specific for the selected radio configuration.

Parameters:

<DSelect>

string

Filename incl. file extension or complete file path

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:DATA DLIS
 MMEM:CDIR "/var/user/Lists"
 BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:DATA:DSEL
 "tdscdma_1"
 selects file `tdscdma_1` as the data source. This file must be in
 specified directory and it must have the file extension
 *.dm_iqd.

Manual operation: See ["Data Source"](#) on page 45

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
 DATA:PATtern <Pattern>, <BitCount>**

Sets the bit pattern

For the traffic channels, this value is specific for the selected radio configuration.

Parameters:

<Pattern> numeric
 *RST: #H0
 <BitCount> integer
 Range: 1 to 64
 *RST: 1

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:DATA:PATT
 #H800FE038,30

Manual operation: See ["Data Source"](#) on page 45

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
 EPRotectioN <EProtection>**

Sets the error protection.

Parameters:

<EProtection> NONE | TURBo3 | CON2 | CON3
 *RST: CON3

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:EPR CON2
 sets the error protection.

Manual operation: See ["Error Protection"](#) on page 46

**[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:IONE <|One>
 [:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:ITWO <|Two>**

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
IONE <IOne>**

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
ITWO <ITwo>**

Activates or deactivates the channel coding interleaver state 1 and 2 off all the transport channels. Interleaver state 1 and 2 can only be set for all the TCHs together. Activation does not change the symbol rate.

Parameters:

<ITwo> 0 | 1 | OFF | ON
*RST: 1

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:ITWO ON

Manual operation: See "[Interleaver 2 State](#)" on page 47

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
RMAtribute <RmAttribute>**

Sets the rate matching.

Parameters:

<RmAttribute> integer
Range: 16 to 1024
*RST: 256

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:RMA 32

Manual operation: See "[Rate Matching Attribute](#)" on page 46

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
STATe <State>**

Sets the state of the transport channel.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: depends on channel

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:STAT ON
enables the transport channel.

Manual operation: See "[State](#)" on page 44

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
TBCount <TbCount>**

Sets the number of transport blocks for the TCH.

Parameters:

<TbCount> integer
 Range: 1 to 24
 *RST: 1

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:TBC 2

Manual operation: See ["Transport Blocks"](#) on page 46

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
 TBSize <TbSize>**

Sets the size of the transport block at the channel coding input.

Parameters:

<TbSize> integer
 Range: 0 to 4096
 *RST: 244(DTCH), 100(DCCH)

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:TBS 4096
 sets the size of transport block of the channel coding input.

Manual operation: See ["Transport Block Size"](#) on page 46

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:DTCH<ch>|DCCH:
 TTInterval <TtInterval>**

Sets the number of frames into which a TCH is divided. This setting also defines the interleaver depth.

Parameters:

<TtInterval> 5MS | 10MS | 20MS | 40MS
 *RST: 20MS(DTCH), 40MS(DCCH)

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:DTCH:TTIN 40MS
 sets the number of frames into which a TCH is divided.

Manual operation: See ["Transport Time Interval"](#) on page 45

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:RUPLayer?

The command queries the resource units on the physical layer needed to generate the selected channel.

Return values:

<RupLayer> string

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:RUPL?
 queries the resource units on the physical layer needed to generate the selected channel.

Usage: Query only

Manual operation: See ["Resource Units On Physical Layer"](#) on page 41

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:SCSMoDe
<ScsMode>
```

Sets the spreading code selection mode for the used transport channels.

Parameters:

```
<ScsMode>          AUTO | USER
*RST:              AUTO
```

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:SCSM AUTO

Manual operation: See "[Spreading Code Selection for Enhanced Channels](#)" on page 42

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:SFORmat?
```

Queries the slot format of the selected channel.

Return values:

```
<SFormat>          string
```

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:SFOR?

Usage: Query only

Manual operation: See "[Slot Format](#)" on page 43

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:SLOTstate<ch>
<SlotState>
```

Queries the state of the slots off cell 1 used to transmit the transport channel.

Parameters:

```
<SlotState>        0 | 1 | OFF | ON
*RST:              depends on slot
```

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:SLOT 3?
queries the state of slot 3.

Manual operation: See "[Mapping On Physical Channels: Select Slots To Use](#)" on page 42

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:STATe <State>
```

Activates or deactivates the enhanced state for the DCH channel coding.

Parameters:

```
<State>            0 | 1 | OFF | ON
*RST:              0
```

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:STAT ON
deactivates the enhanced state for the DCH channel.

Manual operation: See "[State \(DCH\)](#)" on page 40

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:TSCount
<TsCount>
```

Sets the number of timeslots to be used.

Parameters:

```
<TsCount>          integer
                    Range:    1 to 5
                    *RST:    1
```

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:TSC 2

Manual operation: See ["Number of Timeslots \(DCH\)"](#) on page 43

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:TYPE <Type>
```

The command sets the channel coding type.

Parameters:

```
<Type>             RMC12K2 | RMC64K | RMC144K | RMC384K | RMC2048K |
                    HRMC526K | HRMC730K | UP_RMC12K2 | UP_RMC64K |
                    UP_RMC144K | UP_RMC384K | HSDPA | HSUPA | HS_SICH |
                    PLCCH | USER | USER
                    *RST:    RMC12K2
```

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:TYPE RMC12K2
sets the channel coding type to RMC12K2.

Manual operation: See ["Coding Type"](#) on page 40

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:BPFRame?
```

Queries the data bits in the DPDCH component of the DPCH frame at physical level. The value depends on the slot format.

Return values:

```
<BpFrame>         string
```

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:BPFR?

Usage: Query only

Manual operation: See ["Data Bits Per Frame \(10 ms\)"](#) on page 39

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:CRCSize?
```

The command queries the type (length) of the CRC.

Return values:

```
<CrcSize>         NONE | 8 | 12 | 16 | 24
```

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:CRCS?
queries the type (length) of the CRC.

Usage: Query only
Manual operation: See "Size Of CRC" on page 46

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA <Data>

The command selects the data source for the specified channel.

For the traffic channels, this value is specific for the selected radio configuration.

Parameters:

<Data> PN9 | PN11 | PN15 | PN16 | PN20 | PN21 | PN23 | DLISt | ZERO | ONE | PATTErn

PNxx

PRBS data as per CCITT with period lengths between 2^9-1 and $2^{23}-1$ is generated internally.

DLISt

Internal data from a programmable data list is used. The data list can be generated by the Data Editor or generated externally. Data lists are selected in the "Select Data List" field. The data list is selected with the command

BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA:DSEL <data list name>.

ZERO | ONE

Internal 0 and 1 data is used.

PATTErn

A user-definable bit pattern with a maximum length of 64 bits is generated internally. The bit pattern is defined in the "Pattern entry field". The bit pattern is selected with the command

BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA:PATT <bit pattern>.

*RST: PN9

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA PN9
 selects PN9 as the data source of the transport channel.

Manual operation: See "Data Source" on page 45

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:DSElect <DSelect>

Selects an existing data list file from the default directory or from the specific directory.

For general information on file handling in the default and in a specific directory, see section "MMEMory Subsystem" in the R&S SMWuser manual.

For the traffic channels, this value is specific for the selected radio configuration.

Parameters:

<DSelect> string

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA DLIS
 MMEM:CDIR "/var/user/Lists"
 BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA:DSEL
 "tdscdma_1"
 selects file `tdscdma_1` as the data source. This file must be in the specified directory and must have the file extension `*.dm_iqd`.

Manual operation: See ["Data Source"](#) on page 45

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:PATTERN
<Pattern>, <BitCount>

Sets the bit pattern.

For the traffic channels, this value is specific for the selected radio configuration.

Parameters:

<Pattern>	numeric
	*RST: #H0
<BitCount>	integer
	Range: 1 to 64
	*RST: 1

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:DATA:PATT
 #H800FE038,30

Manual operation: See ["Data Source"](#) on page 45

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:EPRotectioN?

Queries the error protection.

Return values:

<EProtection> NONE | TURBo3 | CON2 | CON3

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:EPR?

Usage: Query only

Manual operation: See ["Error Protection"](#) on page 46

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:RMATtribute?

Queries the rate matching.

Return values:

<RmAttribute> integer

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:RMAT?

Usage: Query only

Manual operation: See ["Rate Matching Attribute"](#) on page 46

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:STATe <State>

Queries the state of the transport channel.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:STAT?

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBCount?

Queries the number of transport blocks for the TCH.

Return values:

<TbCount> integer

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:TBC?

Usage: Query only

Manual operation: See "[Transport Blocks](#)" on page 46

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBSize?

Queries the size of the transport block at the channel coding input.

Return values:

<TbSize> integer

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:TBS?

Usage: Query only

Manual operation: See "[Transport Block Size](#)" on page 46

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TTInterval?

Queries the number of frames into which a TCH is divided.

Return values:

<TtInterval> 5MS | 10MS | 20MS | 40MS | 80MS

Example: BB:TDSC:DOWN:CELL1:ENH:BCH:DTCH:TTIN?

Usage: Query only

Manual operation: See "[Transport Time Interval](#)" on page 45

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SCSMMode?

Queries the spreading code predetermined in the standard.

Return values:

<ScsMode> AUTO
*RST: AUTO

Example:

BB:TDSC:DOWN:CELL1:ENH:BCH:SCSM?

Usage:

Query only

Manual operation: See "[Spreading Code Selection \(BCH\)](#)" on page 38

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SFORmat?

The command queries the slot format of the selected channel. A slot format defines the complete structure of a slot made of data and control fields and includes the symbol rate. The slot format (and thus the symbol rate, the pilot length, and the TFCI State) depends on the coding type selected.

Return values:

<SFormat> string

Example:

BB:TDSC:DOWN:CELL1:ENH:BCH:SFOR?
queries the channel coding type.

Usage:

Query only

Manual operation: See "[Slot Format](#)" on page 39

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SLOTstate<ch0>?

Queries the state of the slots off cell 1 used to transmit the broadcast channels.

Slot 0 is always on and all the other slots are always off.

Return values:

<SlotState> 0 | 1 | OFF | ON
*RST: 0

Example:

BB:TDSC:DOWN:CELL1:ENH:BCH:SLOT1?

Usage:

Query only

Manual operation: See "[Mapping On Physical Channels: BCH mapped to <Slot> 0, P-CCPCH1/2](#)" on page 38

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:STATe <State>

Activates and deactivates the enhanced state for the P-CCPCH 1/2 channel.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

BB:TDSC:DOWN:CELL1:ENH:BCH:STAT ON

Manual operation: See "[State \(BCH\)](#)" on page 38

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:TYPE?

The command queries the channel coding type.

Return values:

<Type> BCHSfn

Example:

BB:TDSC:DOWN:CELL1:ENH:BCH:TYPE?
queries the channel coding type.

Usage:

Query only

Manual operation: See "Coding Type (BCH)" on page 38

5.9 Channel Settings

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh: EUCc:CCOunt.....	132
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh: EUCc:HPID.....	133
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh: EUCc:RSNumber.....	133
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh: EUCc:TFCI.....	133
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DATA.....	134
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DATA:DSElect.....	134
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DATA:PATtern.....	134
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:SYNC:LENGth.....	135
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:SYNC:PATtern.....	135
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:SYNC:REPetition.....	135
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:TFCI:LENGth.....	136
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:TFCI:VALue.....	136
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:TPC:DATA.....	136
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:TPC:DATA:DSElect.....	137
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:TPC:DATA:PATtern.....	137
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: DPCCh:TPC:READ.....	137
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: ENHanced?.....	138
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:MSHiff?..	138

[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:POWer...	138
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SCODE...	139
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SFACtor.	139
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>: SFORmat.....	139
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:STATe....	140
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:TYPE.....	140
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:USER....	140
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:DCONflict?.....	141
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:STATe.....	141
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:MODE.....	141
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA.....	142
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:DSElect.....	142
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:PATtern.....	143
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:LENGth.....	143
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:MSHift?.....	143
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:PCORrection.....	143
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:POWer.....	144
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SCODE.....	144
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFACtor.....	144
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFORmat?.....	145
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:STATe.....	145
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:USER.....	145
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:DISTance.....	146
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:PCORrection?.....	146
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:POWer.....	146
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:PSTep.....	147
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:REPetition.....	147
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:STARt.....	147
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:SLENgth?.....	148

**[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:CCOunt <CCount>**

Sets the number of the E-DCH Uplink Control Channels (E-UCCH).

Parameters:

<CCount> integer
 Range: 0 to 8
 *RST: 0

Example:

```
BB:TDSC:UP:CELL1:SLOT1:CHAN7:TYPE E_PUCH_QPSK
sets channel type E-PUCH QPSK
BB:TDSC:UP:CELL1:SLOT1:CHAN7:DPCC:EUCC:CCO 5
sets number of E-UCCH channels
```

Manual operation: See "Number of E-UCCH Channels" on page 77

**[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:HPID <Hpid>**

Sets the HARQ process ID.

Parameters:

<Hpid> integer
Range: 0 to 3
*RST: 0

Example: BB:TDSC:UP:CELL1:SLOT1:CHAN7:TYPE E_PUCH_QPSK
sets channel type E-PUCH QPSK
BB:TDSC:UP:CELL1:SLOT1:CHAN7:DPCC:EUCC:HPID 2
sets number HARQ process ID

Manual operation: See "[HARQ Process ID](#)" on page 77

**[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:RSNumber <RsNumber>**

Sets the retransmission sequence number.

Parameters:

<RsNumber> integer
Range: 0 to 3
*RST: 0

Example: BB:TDSC:UP:CELL1:SLOT1:CHAN7:TYPE E_PUCH_QPSK
sets channel type E-PUCH QPSK
BB:TDSC:UP:CELL1:SLOT1:CHAN7:DPCC:EUCC:RSN 2
sets retransmission sequence number

Manual operation: See "[Retransmission Sequence Number \(E-UCCH\)](#)" on page 77

**[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:EUCC:TFCI <Tfci>**

Enters the value of the TFCI field.

Parameters:

<Tfci> integer
Range: 0 to 63
*RST: 0

Example: BB:TDSC:UP:CELL1:SLOT1:CHAN7:TYPE E_PUCH_QPSK
sets channel type E-PUCH QPSK
BB:TDSC:UP:CELL1:SLOT1:CHAN7:DPCC:EUCC:TFCI 10
sets the TFCI value

Manual operation: See "[E-TFCI Value](#)" on page 77

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
  DATA <Data>
```

The command determines the data source for the selected channel.

Parameters:

```
<Data>          PN9 | PN11 | PN15 | PN16 | PN20 | PN21 | PN23 | DLISt |
                ZERO | ONE | PATTern
```

PNxx
PRBS data as per CCITT with period lengths between 29-1 and 223-1 is generated internally.

DLISt
Internal data from a programmable data list is used.

ZERO | ONE
Internal 0 and 1 data is used.

PATTern
A user-definable bit pattern with a maximum length of 64 bits is generated internally.

```
*RST:          PN9
```

Example: `BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DATA PN9`
sets the data source for the selected channel to PN9.

Manual operation: See "[Data](#)" on page 68

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
  DATA:DSElect <DSelect>
```

Selects an existing data list file from the default directory or from the specific directory.

Parameters:

```
<DSelect>      string
```

Example: `BB:TDSC:UP:CELL1:SLOT3:CHAN6:DATA DLIS`
`MMEM:CDIR "/var/user/Lists"`
`BB:TDSC:UP:CELL1:SLOT3:CHAN6:DATA:DSEL`
`"tdscdma_1"`
selects file `tdscdma_1` as the data source. This file must be in the directory and must have the file extension `*.dm_iqd`.

Manual operation: See "[Data](#)" on page 68

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
  DATA:PATTern <Pattern>, <BitCount>
```

Determines the bit pattern. The first parameter determines the bit pattern (choice of hexadecimal, octal, or binary notation), the second specifies the number of bits to use.

Parameters:

```
<Pattern>      numeric
                *RST:      #H0
```

<BitCount> integer
 Range: 1 to 64
 *RST: 1

Example: BB:TDSC:UP:CELL1:SLOT3:CHAN6:DATA:PATT #H3F, 8
 defines the bit pattern.

Manual operation: See ["Data"](#) on page 68

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
 DPCCh:SYNC:LENGth <Length>**

Sets the length of the sync shift and the length of the TPC field in bits. The available values depend on the slot format.

Parameters:

<Length> 0 | 2 | 3 | 4 | 8 | 16 | 32 | 48
 *RST: 0

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:SYNC:LENG 2

Manual operation: See ["Number of Sync Shift & TPC Bits"](#) on page 75

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
 DPCCh:SYNC:PATTern <Pattern>**

Sets the bit pattern for the sync shift.

Parameters:

<Pattern> string
 The maximum pattern length is 64 bits.

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:SYNC:PATT
 10-01

Manual operation: See ["Sync Shift Pattern"](#) on page 75

**[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
 DPCCh:SYNC:REPetition <Repetition>**

Sets the value for the sync shift repetition.

Parameters:

<Repetition> integer
 Range: 1 to 8
 *RST: 1

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:SYNC:REP 1

Manual operation: See ["Sync Shift Repetition M"](#) on page 76

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
  DPCCh:TFCI:LENGth <Length>
```

Sets the length of the TFCI field in bits.

Parameters:

```
<Length>          0 | 4 | 6 | 8 | 12 | 16 | 24 | 32 | 48
*RST:              0
```

Example:

```
BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:TFCI:LENG
12
sets the length of the TFCI field to 12 bits.
```

Manual operation: See ["Number of TFCI Bits"](#) on page 74

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
  DPCCh:TFCI:VALue <Value>
```

The command sets the value of the TFCI field.

Parameters:

```
<Value>           integer
Range:            0 to 1023
*RST:              0
```

Example:

```
BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:TFCI:VAL 0
sets the value of the TFCI field to 0.
```

Manual operation: See ["TFCI Value"](#) on page 74

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
  DPCCh:TPC:DATA <Data>
```

Sets the data source for the TPC field of the DPCCH.

Parameters:

```
<Data>            ZERO | ONE | PATtern | DLISt
DLISt
A data list is used.
ZERO | ONE
Internal 0 and 1 data is used.
PATtern
Internal data is used.
*RST:              PATtern
```

Example:

```
BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:TPC:DATA
PATT
BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:TPC:DATA:
PATT #H3F,8
```

Manual operation: See ["TPC Source"](#) on page 78

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:TPC:DATA:DSElect <DSelect>
```

Selects an existing data list file from the default directory or from the specific directory.

For the traffic channels, this value is specific for the selected radio configuration.

Parameters:

<DSelect> string

Example:

```
BB:TDSC:DOWN:CELL1:SLOT3:CHAN5:DPCC:TPC:DATA
DLIS
```

```
MMEM:CDIR "/var/user/Lists"
```

```
BB:TDSC:DOWN:CELL1:SLOT3:CHAN5:DPCC:TPC:DATA:
DSEL "tdscdma_1"
```

selects file `tdscdma_1` as the data source. This file must be in the directory and must have the file extension `*.dm_iqd`.

Manual operation: See "[TPC Source](#)" on page 78

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:TPC:DATA:PATtern <Pattern>, <BitCount>
```

Sets the bit pattern and the maximum bit pattern length.

Parameters:

<Pattern> numeric

```
*RST:        #H1
```

<BitCount> integer

```
Range:       1 to 64
```

```
*RST:        2
```

Example:

```
BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:TPC:DATA:
PATT #H3F,8
```

defines the bit pattern.

Manual operation: See "[TPC Source](#)" on page 78

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
DPCCh:TPC:READ <Read>
```

Sets the read out mode for the bit pattern of the TPC field.

Parameters:

<Read> CONTInuous | S0A | S1A | S01A | S10A

CONTInous

The TPC bits are used cyclically.

S0A

The TPC bits are used once and then the TPC sequence is continued with 0 bits.

S1A

The TPC bits are used once and then the TPC sequence is continued with 1 bit.

S01A

The TPC bits are used once and then the TPC sequence is continued with 0 and 1 bits alternately

S10A

The TPC bits are used once, and then the TPC sequence is continued with 1 and 0 bits alternately

*RST: CONTInuous

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:DPCC:TPC:READ
S01A

Manual operation: See "Read Out Mode" on page 79

**[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
ENHanced?**

Queries the enhanced state. If the enhanced state is set to ON, the channel coding cannot be changed.

Return values:

<Enhanced> 0 | 1 | 2 | OFF | ON | NOvalue

*RST: NOvalue

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:ENH?

Usage: Query only

Manual operation: See "Enhanced" on page 67

**[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
MSHift?**

Queries the midamble shift.

Return values:

<MShift> integer

Range: 0 to 128

*RST: 120

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:MSH?

Usage: Query only

Manual operation: See "Midamble Shift" on page 74

**[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
POWer <Power>**

Sets the channel power in dB.

Parameters:

<Power> float
 Range: -80 to 0
 Increment: 0.01
 *RST: 0

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:POW -20

Manual operation: See "[Power/dB](#)" on page 68

[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SCODE <SCode>

Sets the spreading code for the selected channel. The code channel is spread with the set spreading code. The range of values of the spreading code depends on the channel type and the spreading factor. Depending on the channel type, the range of values can be limited.

Parameters:

<SCode> integer
 Range: 1 to 16
 *RST: 1

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:SCOD 1
 set the spreading code for channel 6 to 1.

Manual operation: See "[Sprd. Code](#)" on page 68

[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SFACTOR <SFactor>

Sets the spreading factor for the selected channel. The selection depends on the channel type and interacts with the slot format.

Parameters:

<SFactor> 1 | 2 | 4 | 8 | 16
 *RST: 16

Example: BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:SFAC 16

Manual operation: See "[Sprd. Fact.](#)" on page 68

[[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SFORMAT <SFormat>

Sets the slot format for the selected channel. A slot format defines the complete structure of a slot made of data and control fields and includes the symbol rate. The slot format displays changes when a change is made to the "Number of TFCI Bits" and the "Number of Sync Shift & TPC Bits" field settings.

Parameters:

<SFormat> integer
 Range: 0 to 69
 *RST: -

Example:

BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:SFOR 0
 sets the slot format for channel 6 to 0.

Manual operation: See "[Slot Format](#)" on page 67

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
 STATE <State>**

Activates or deactivates the channel.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

BB:TDSC:UP:CELL1:SLOT3:CHAN6:STAT ON

Manual operation: See "[State](#)" on page 69

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
 TYPE <Type>**

Sets the channel type.

In the uplink, the channel type is fixed for channel number 0. In the downlink, the channel type is fixed for channel numbers 0 to 5. For the remaining numbers, the choice lies between the relevant standard channels and the high speed channels.

Parameters:

<Type> P_CCPCH1 | P_CCPCH2 | S_CCPCH1 | S_CCPCH2 | FPACH |
 PDSCH | DPCH_QPSK | DPCH_8PSK | HS_SCCH1 |
 HS_SCCH2 | HS_PDS_QPSK | HS_PDS_16QAM | PUSCH |
 UP_DPCH_QPSK | UP_DPCH_8PSK | HS_SICH |
 HS_PDS_64QAM | E_PUCH_QPSK | E_PUCH_16QAM |
 E_RUCCH | PLCCH | EAGCH | EHICH
 *RST: depends on channel number

Example:

BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:TYPE DPC_QPSK
 sets the channel type DPC_QPSK for channel 6 of the channel
 table.

Manual operation: See "[Channel Type](#)" on page 67

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:
 USER <User>**

Sets the number of the user.

Parameters:

<User> integer
 Range: 1 to 16
 *RST: 1

Example:

BB:TDSC:DOWN:CELL4:SLOT3:CHAN6:USER 3
 sets the number of the users to 3.

Manual operation: See "[Crt.User/Mid.Shift](#)" on page 67

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:DCONflict?

Queries the global domain conflict state per slot.

Return values:

<DConflict> 0 | 1 | OFF | ON
 *RST: 0

Example:

BB:TDSC:UP:CELL1:SLOT3:DCON?

Usage:

Query only

Manual operation: See "[Dom. Conf.](#)" on page 69

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:SLOT<ch0>:STATe <State>

Activates and deactivates the slot in the subframe.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

BB:TDSC:DOWN:CELL1:SLOT0:STAT ON

Manual operation: See "[Slot Icon](#)" on page 36

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:MODE <Mode>

Sets the mode in which the slot is to work.

Parameters:

<Mode> DEDicated | PRACH

DEDicated

The instrument generates a signal with a dedicated physical control channel (DPCCH) and up to six dedicated physical data channels (DPDCH). The signal is used for voice and data transmission.

PRACH

The instrument generates a single physical random access channel (PRACH). This channel is needed to set up the connection between the mobile station and the base station.

*RST: DEDicated

Example: BB:TDSC:UP:CELL4:SLOT3:MODE PRAC

Manual operation: See "[Slot Mode](#)" on page 64

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA
<Data>**

The command determines the data source for the PRACH.

Parameters:

<Data> PN9 | PN11 | PN15 | PN16 | PN20 | PN21 | PN23 | DLIS |
ZERO | ONE | PATtern

PNxx

PRBS data as per CCITT with period lengths between 2^9-1 and $2^{23}-1$ is generated internally.

DLIS

Internal data from a programmable data list is used.

ZERO | ONE

Internal 0 and 1 data is used.

PATtern

A user-definable bit pattern with a maximum length of 64 bits is generated internally.

*RST: PN9

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:DATA PN9
selects PN9 as the data source for the PRACH.

Manual operation: See "[Data Source \(PRACH\)](#)" on page 83

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:
DSElect <DSelect>**

Selects an existing data list file from the default directory or from the specific directory.

Parameters:

<DSelect> string
Filename incl. file extension or complete file path

Example: BB:TDSC:UP:CELL1:SLOT3:PRAC:MSG:DATA DLIS
MMEM:CDIR "/var/user/Lists"
BB:TDSC:UP:CELL1:SLOT3:PRAC:MSG:DATA:DSEL
"tdscdma_1"
Selects file `tdscdma_1` as the data source. This file must be in the directory and it must have the file extension `*.dm_iqd`

Manual operation: See "[Data Source \(PRACH\)](#)" on page 83

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:
PATTern <Pattern>, <BitCount>**

Determines the bit pattern. The first parameter determines the bit pattern (choice of hexadecimal, octal or binary notation), the second specifies the number of bits to use.

Parameters:

<Pattern>	numeric
	*RST: #H0
<BitCount>	integer
	Range: 1 to 64
	*RST: 1

Example: BB:TDSC:UP:CELL1:SLOT3:PRAC:MSG:DATA:PATT #H3F,
8
defines the bit pattern.

Manual operation: See " [Data Source \(PRACH\)](#) " on page 83

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:LENGth
<Length>**

Sets the message length of the random access channel in subframes.

Parameters:

<Length>	1 2 4
	*RST: 1

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:LENG 1

Manual operation: See " [Message Length](#) " on page 82

[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:MSHift?

Queries the value of the midamble shift.

Return values:

<MShift>	integer
	Range: 0 to 128
	*RST: 120

Example: BB:TDSC:UP:CELL1:SLOT3:PRAC:MSG:MSH?

Usage: Query only

Manual operation: See " [Midamble Shift \(PRACH\)](#) " on page 84

**[[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:
PCORrection <PCorrection>**

Queries the value of the power correction.

Parameters:

<PCorrection> float
 Range: -1E10 to 1E10
 Increment: 0.01
 *RST: -

Example:

BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:POW -10
 sets the power of the PRACH message part
 BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:PCOR?
 queries the value of the power correction.
 Response: 2.99086185076844

Manual operation: See " [Power \(RACH Message Part\)](#) " on page 83

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:POWER
 <Power>

Sets the power of the PRACH message part.

Parameters:

<Power> float
 Range: -80 to 0
 Increment: 0.01
 *RST: 0

Example:

BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:POW 1

Manual operation: See " [Power \(RACH Message Part\)](#) " on page 83

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SCODE
 <SCode>

Sets the spreading code for the PRACH. The code channel is spread with the set spreading code.

Parameters:

<SCode> integer
 Range: 1 to 16
 *RST: 1

Example:

BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:SCOD 16
 sets the power of the PRACH message part.

Manual operation: See " [Spreading Code \(PRACH\)](#) " on page 83

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFACTOR
 <Sfactor>

Sets the spreading factor for the PRACH.

Parameters:

<Sfactor> 4 | 8 | 16
 *RST: 16

Example:

BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:SFAC 16

Manual operation: See "[Spreading Factor \(PRACH\)](#)" on page 83

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFORmat?

Queries the slot format of the PRACH. The slot format depends on the selected spreading factor.

Return values:

<SFormat> integer
 Range: 0 to 25
 *RST: 0

Example:

BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:SFOR 1

Usage:

Query only

Manual operation: See "[Slot Format \(PRACH\)](#)" on page 83

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:STATE<State>

Activates or deactivates the RACH (random access channel) message part.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:STAT ON

Manual operation: See "[State \(RACH Message Part\)](#)" on page 82

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:USER<User>

Sets user number.

Parameters:

<User> integer
 Range: 1 to 16
 *RST: 1

Example:

BB:TDSC:UP:CELL1:SLOT3:PRAC:MSG:USER 1

Manual operation: See "[Current User \(PRACH\)](#)" on page 84

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:DISTance
 <Distance>

Sets the value to vary the timing between UpPTS and RACH.

Parameters:

<Distance> integer
 Range: 1 to 4
 *RST: 1

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:DIST 1

Manual operation: See " [Distance UpPTS](#) " on page 81

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:
PCORrection?

Queries the power correction of the UpPTS.

The value is computed based on:

- UpPTS power
 BB:TDSC:UP:CELL:SLOT:PRAC:PTS:POW
- Power step
 BB:TDSC:UP:CELL:SLOT:PRAC:PTS:PST
- Message power
 BB:TDSC:UP:CELL:SLOT:PRAC:MSG:POW
- UpPTS length, message length
 BB:TDSC:UP:CELL:SLOT:PRAC:MSG:LENG
- ARB sequence length
 BB:TDSC:SLEN

Return values:

<PCorrection> float
 Range: -1E10 to 1E10
 Increment: 0.01
 *RST: 19.03

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:POW -12
 BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:PCOR?
 Response: 0.8890863332626

Usage: Query only

Manual operation: See " [Power](#) " on page 81

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:POWer
 <Power>

Sets the power of the UpPTS.

Parameters:

<Power> float
 Range: -80 to 0
 Increment: 0.01
 *RST: 0

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:POW -12

Manual operation: See " [Power](#) " on page 81

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:PSTep
 <PStep>

Sets the power by which the UpPTS is increased from repetition to repetition.

Parameters:

<PStep> float
 Range: 0 to 10
 Increment: 0.01
 *RST: 0

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:PST 3

Manual operation: See " [Power Step](#) " on page 80

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:REPetition
 <Repetition>

Sets the number of UpPTS repetitions before a PRACH burst happens.

Parameters:

<Repetition> integer
 Range: 1 to 10
 *RST: 1

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:REP 1

Manual operation: See " [UpPTS Repetition](#) " on page 82

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:STARt
 <Start>

Sets the number of the subframe in which the first UpPTS should be transmitted.

Parameters:

<Start> integer
 Range: 0 to 10
 *RST: 0

Example: BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:STAR 3

Manual operation: See " [UpPTS Start](#) " on page 81

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:SLENgth?

Queries the sequence length of the PRACH slot.

The value is computed based on:

- Start Subframe
BB:TDSC:UP:CELL:SLOT:PRAC:PTS:STAR
- UpPTS repetition
BB:TDSC:UP:CELL:SLOT:PRAC:PTS:REP
- Distance UpPTS and RACH
BB:TDSC:UP:CELL:SLOT:PRAC:PTS:DIST
- Message length
BB:TDSC:UP:CELL:SLOT:PRAC:MSG:LENG

Return values:

<SLength> float
Range: 0.5 to 13.5
Increment: 0.5
*RST: 0.5

Example:

BB:TDSC:UP:CELL:SLOT:PRAC:PTS:STAR 3

Sets the number of the subframe in which the first UpPTS is transmitted.

BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:REP 2

Sets the number of UpPTS repetitions before a PRACH burst happens.

BB:TDSC:UP:CELL4:SLOT3:PRAC:PTS:DIST 2

Sets the number of the subframe in which the first UpPTS is transmitted.

BB:TDSC:UP:CELL4:SLOT3:PRAC:MSG:LENG 1

Sets the message length of the random access channel to one subframe.

BB:TDSC:UP:CELL4:SLOT3:PRAC:SLEN?

Queries the sequence length.

Response: 3.5

Usage: Query only

Manual operation: See " [Sequence Length](#) " on page 81

5.10 HSDPA/HSUPA Settings

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:RMC.....	149
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SCCH.....	150
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SPATtern?.....	150
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TBS:TABLE.....	150
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TTIDistance.....	151
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:UEID.....	151
[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:VIBSize.....	151

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:EUCTti.....	151
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:FRC.....	152
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSEquence.....	152
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSNumber?.....	152
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:SFACTOR.....	153
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:TBS:TABLE.....	153
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: BPAYload?.....	153
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:CRATE?....	154
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:CTSCount.	154
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:DATA.....	154
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:DATA: DSElect.....	155
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:DATA: PATtern.....	155
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: HARQ:LENGth.....	155
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: HARQ:MODE.....	156
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:MIBT?.....	156
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: MODulation.....	156
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:NCBTti?...	157
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: RVParameter.....	157
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: RVSequence.....	157
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: SFORmat?.....	158
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:TBS: INDEX.....	158
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:TSCount...	159
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: TTINterval?.....	159
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA: UECategory?.....	159

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:RMC <Rmc>

Enables a predefined set of RMC channels or fully configurable user mode.

Parameters:

<Rmc> HRMC_0M5_QPSK | HRMC_1M1_QPSK |
 HRMC_1M1_16QAM | HRMC_1M6_QPSK |
 HRMC_1M6_16QAM | HRMC_2M2_QPSK |
 HRMC_2M2_16QAM | HRMC_2M8_QPSK |
 HRMC_2M8_16QAM | HRMC_64QAM_16UE |
 HRMC_64QAM_19UE | HRMC_64QAM_22UE | USER
 *RST: HRMC_0M5_QPSK

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:RMC
 HRMC_2M8_QPSK
 sets the RMC mode

Manual operation: See " [RMC Configuration](#) " on page 52

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SCCH <Scch>

Enables/disables the HS-SCCH.

Parameters:

<Scch> 0 | 1 | OFF | ON
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:SCCH ON

Manual operation: See " [HS-SCCH State](#) " on page 55

[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SPATtern?

Queries the distribution of packets over time.

The signaling pattern is cyclically repeated.

Return values:

<SPattern> string
 A sequence of HARQ-IDs and "-".
 A HARQ-ID indicates a packet, a "-" indicates no packet.

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:TTID 2
 BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:HARQ:LENG 4
 BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:SPAT?
 Response: '0,-,1,-2,-,3,-'

Usage: Query only

Manual operation: See " [Signaling Pattern](#) " on page 61

**[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TBS:TABLE
 <Table>**

Sets the transport block size table, according to the specification 3GPP TS 25.321.

Parameters:

<Table> C1TO3 | C4TO6 | C10TO12 | C7TO9 | C13TO15 | C16TO18 |
 C19TO21 | C22TO24
 *RST: C1TO3

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:TSB:TABL
 C13TO15

Manual operation: See " [Transport Block Size Table](#) " on page 59

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TTIDistance <TtiDistance>

Sets the inter-TTI distance. The inter-TTI is the distance between two packets in HSDPA packet mode and determines whether data is sent each TTI or there is a DTX transmission in some of the TTIs.

An inter-TTI distance of 1 means continuous generation.

Parameters:

<TtiDistance> integer
 Range: 1 to 8
 *RST: 1

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:TTID 2

Manual operation: See " [Inter TTI Distance](#) " on page 61

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:UEID <Ueid>

Sets the UE identity.

Parameters:

<Ueid> integer
 Range: 0 to 65535
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:UEID 2
 sets the UE ID

Manual operation: See " [UEID \(H-RNTI\)](#) " on page 55

[:SOURce<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:VIBSize <VibSize>

Sets the size of the virtual IR buffer.

Parameters:

<VibSize> integer
 Range: dynamic to 63360
 Increment: 704
 *RST: 2816

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:VIBS 2800
 sets the size of the virtual IR buffer

Manual operation: See " [Virtual IR Buffer Size \(Per HARQ process\)](#) " on page 60

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:EUCTti <Euctti>

Sets the number of E-UCCH channels per TTI.

Parameters:

<Euctti> integer
 Range: 1 to 8
 *RST: 4

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:EUCT 2
 sets the number of channels

Manual operation: See " [Number of E-UCCH per TTI](#) " on page 57

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:FRC <Frc>

Selects a predefined E-DCH fixed reference channel or fully configurable user mode.

Parameters:

<Frc> 1 | 2 | 3 | 4 | USER
 *RST: 1

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:EUCT 2

Manual operation: See " [E-DCH Fixed Reference Channel \(FRC\)](#) " on page 54

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSEQUENCE <RSequence>

(for "HSUPA" and "HARQ Mode" set to constant NACK)

Sets the retransmission sequence.

Parameters:

<RSequence> string
 *RST: 0

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:TYPE HSUPA
 BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:HARQ:MODE CNAC
 BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:RSEQ '0,2,3'

Manual operation: See " [Retransmission Sequence](#) " on page 63

[:SOURCE<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSNUMBER?

(for HARQ Mode set to constant ACK)

Queries the retransmission sequence number.

The value is fixed to 0.

Return values:

<RsNumber> integer
 Range: 0 to 0
 *RST: 0

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:HARQ:MODE CACK
 BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:RSN?
 Response: 0

Usage: Query only

Manual operation: See " [Retransmission Sequence Number](#) " on page 63

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:SFActor
 <SFactor>

Selects the spreading factor for the FRC.

Parameters:
 <SFactor> 1 | 2 | 4 | 8 | 16
 *RST: 4

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:SFAC 2
 sets the spreading factor

Manual operation: See " [Spreading Factor \(FRC\)](#) " on page 57

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:TBS:TABLE
 <Table>

Sets the transport block size table, according to the specification 3GPP TS 25.321, annex BC.

Parameters:
 <Table> C1TO2 | C3TO6
 *RST: C1TO2

Example: BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:TBS:TABL C3TO6

Manual operation: See " [Transport Block Size Table 0](#) " on page 59

[:SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
BPAYload?

Queries the payload of the information bit. i.e. transport block size. This value determines the number of transport layer bits sent in each TTI before coding.

Return values:
 <BPayload> integer

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:BPAY?

Usage: Query only

Manual operation: See " [Information Bit Payload \(Ninf\)](#) " on page 60

[:SOURce<hw>] : BB : TDSCdma : DOWN | UP : CELL <st> : ENH : DCH : HSDPA | HSUPA : CRATe ?

Queries the coding rate.

Return values:

<CRate> float

Example: BB : TDSC : DOWN | UP : CELL1 : ENH : DCH : HSDPA | HSUPA : CRAT ?

Usage: Query only

Manual operation: See " Coding Rate " on page 60

[:SOURce<hw>] : BB : TDSCdma : DOWN | UP : CELL <st> : ENH : DCH : HSDPA | HSUPA : CTSCCount <CtsCount>

Sets the number of physical channels per timeslot.

Parameters:

<CtsCount> integer

Range: 1 to 14

*RST: 10(downlink), 1(uplink)

Example: BB : TDSC : DOWN | UP : CELL1 : ENH : DCH : HSDPA | HSUPA : CTSC
2

Manual operation: See " Number of HS-PDSCH/E-DCH Codes per TS " on page 56

[:SOURce<hw>] : BB : TDSCdma : DOWN | UP : CELL <st> : ENH : DCH : HSDPA | HSUPA : DATA <Data>

The command determines the data source for the HSDPA/HSUPA channels.

Parameters:

<Data> PN9 | PN11 | PN15 | PN16 | PN20 | PN21 | PN23 | DLISt | ZERO | ONE | PATTeRn

PNxx

PRBS data as per CCITT with period lengths between 2^9-1 and $2^{23}-1$ is generated internally.

DLISt

Internal data from a programmable data list is used.

ZERO | ONE

Internal 0 and 1 data is used.

PATTeRn

A user-definable bit pattern with a maximum length of 64 bits is generated internally.

*RST: PN9

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:DATA
PN11
selects the data source

Manual operation: See " [Data Source](#) " on page 58

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
DATA:DSElect <DSelect>**

Selects an existing data list file from the default directory or from the specific directory.

Parameters:

<DSelect> string
Filename incl. file extension or complete file path

Example: BB:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:DATA DLIS
MMEM:CDIR "/var/user/Lists"
BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:DATA:
DSEL "tdscdma_1"
Selects file `tdscdma_1` as the data source. This file must be in
the directory and must have the file extension `*.dm_iqd`

Manual operation: See " [Data Source](#) " on page 58

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
DATA:PATtern <Pattern>, <BitCount>**

Determines the bit pattern. The first parameter determines the bit pattern (choice of hexadecimal, octal or binary notation), the second specifies the number of bits to use.

Parameters:

<Pattern> numeric
*RST: #H0

<BitCount> integer
Range: 1 to 64
*RST: 1

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:DATA:
PATT #H3F, 8
defines the bit pattern.

Manual operation: See " [Data Source](#) " on page 58

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
HARQ:LENGth <Length>**

Sets the number of HARQ processes. This value determines the distribution of the payload in the subframes and depends on the inter-TTI distance.

A minimum of three HARQ Processes are required to achieve continuous data transmission.

Parameters:

<Length> integer
 Range: 1 to 8
 *RST: 4

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:HARQ:LENG 5

Manual operation: See " [Number of HARQ Processes](#) " on page 61

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
 HARQ:MODE <Mode>**

Sets the HARQ simulation mode.

Parameters:

<Mode> CACK | CNACK

CACK

New data is used for each new TTI. This mode is used to simulate maximum throughput transmission.

CNACK

Enables NACK simulation, i.e. depending on the sequence selected with command

BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:RVS packets are retransmitted. This mode is used for testing with varying redundancy version.

*RST: CACK

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:HARQ:
 MODE CNACK
 sets the HARQ mode

Manual operation: See " [HARQ Mode](#) " on page 62

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
 MIBT?**

Queries maximum information bits sent in each TTI before coding.

Return values:

<Mibt> float
 Increment: 0.1

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:MIBT?

Usage: Query only

Manual operation: See " [Maximum Information Bit Throughput /kbps](#) " on page 56

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
 MODulation <Modulation>**

Sets the modulation scheme for each HSDPA RMC or HSUPA FRC.

The HSUPA FRCs do not support modulation scheme 64QAM.

Parameters:

<Modulation> QPSK | QAM16 | QAM64
*RST: QPSK

Example:

BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:MOD
QAM16

Manual operation: See "[Modulation](#)" on page 58

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
NCBTti?**

Queries the number of bits after coding.

Return values:

<NcbTti> integer

Example:

BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:NCBT?

Usage:

Query only

Manual operation: See "[Number of Coded Bits Per TTI](#)" on page 59

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
RVParameter <RvParameter>**

(for HARQ Mode set to constant ACK)

Sets the redundancy version parameter, i.e. indicates which redundancy version of the data is sent.

Parameters:

<RvParameter> integer
Range: 0 to 7
*RST: 0

Example:

BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:HARQ:
MODE CACK
BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:RVP 2

Manual operation: See "[Redundancy Version Parameter](#)" on page 63

**[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
RVSequence <RvSequence>**

For HARQ mode set to constant NACK, sets the retransmission sequence.

For HSUPA, the command is a query only.

Parameters:

<RvSequence> string of 30 coma-separated values
 The sequence length determines the maximum number of retransmissions. New data is retrieved from the data source after reaching the end of the sequence.
 *RST: 0

Example:

```
BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:HARQ:
MODE CNAC
BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:RVS '0,2,1'
BB:TDSC:DOWN:CELL1:ENH:DCH:TYPE HSUPA
BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:HARQ:MODE CNAC
BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:RSEQ '0,2,3'
BB:TDSC:UP:CELL1:ENH:DCH:HSUPA:RVS?
Response: '0,2,1'
```

Manual operation: See "[Redundancy Version Sequence](#)" on page 63

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:SFORmat?

Queries the slot format of the selected channel.

A slot format defines the complete structure of a slot made of data and control fields. The slot format depends on the coding type selected.

Return values:

<SFormat> string

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:SFOR?

Usage: Query only

Manual operation: See "[Slot Format](#)" on page 57

[:SOURCE<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:TBS:INDex <Index>

Sets the index for the corresponding table, as described in 3GPP TS 25.321.

Parameters:

<Index> integer
 Range: 0 to 63
 *RST: -

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:TBS:IND 20

Manual operation: See "[Transport Block Size Index](#)" on page 60

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
  TSCount <TsCount>
```

Sets the number of timeslots.

Parameters:

```
<TsCount>          integer
                    Range:    2 to 5
                    *RST:     2
```

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:TSC 3

Manual operation: See " [Number of HS-PDSCH/E-DCH Timeslots](#) " on page 56

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
  TTInterval?
```

Queries the transmission time interval (TTI).

Return values:

```
<TtInterval>      5MS
```

Example: BB:TDSC:DOWN|UP:CELL1:ENH:DCH:HSDPA|HSUPA:TTIN?
Response: 5MS

Usage: Query only

Manual operation: See " [Transmission Time Interval \(TTI\)](#) " on page 57

```
[ :SOURce<hw>]:BB:TDSCdma:DOWN|UP:CELL<st>:ENH:DCH:HSDPA|HSUPA:
  UECategory?
```

Queries the UE category that is minimum required to receive the selected RMC or FRC.

Return values:

```
<UeCategory>      integer
```

Example: BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:RMC
HRMC_2M8_16QAM
BB:TDSC:DOWN:CELL1:ENH:DCH:HSDPA:UEC?
Response: 13

Usage: Query only

Manual operation: See " [UE Category](#) " on page 56

List of Commands

[:SOURCE<hw>]:BB:TDSCdma:CLIPping:LEVel.....	99
[:SOURCE<hw>]:BB:TDSCdma:CLIPping:MODE.....	99
[:SOURCE<hw>]:BB:TDSCdma:CLIPping:STATe.....	100
[:SOURCE<hw>]:BB:TDSCdma:CLOCK:MODE.....	109
[:SOURCE<hw>]:BB:TDSCdma:CLOCK:SOURce.....	109
[:SOURCE<hw>]:BB:TDSCdma:COPY:DESTination.....	92
[:SOURCE<hw>]:BB:TDSCdma:COPY:EXECute.....	93
[:SOURCE<hw>]:BB:TDSCdma:COPY:SOURce.....	92
[:SOURCE<hw>]:BB:TDSCdma:CRATe:VARiation.....	93
[:SOURCE<hw>]:BB:TDSCdma:CRATe?.....	93
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:MODE.....	111
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:POWer.....	112
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:DWPTs:STATe?.....	112
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:BPFRame?.....	126
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:CRCSIZE?.....	126
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA.....	127
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:DSElect.....	127
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:DATA:PATtern.....	128
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:EPROTectiOn?.....	128
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:IONE.....	122
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:ITWO.....	122
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:RMATtribute?.....	128
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:STATe.....	129
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBCOUNT?.....	129
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TBSIZE?.....	129
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:DTCH:TTIInterval?.....	129
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SCSMODE?.....	129
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SFORmat?.....	130
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:SLOTstate<ch0>?.....	130
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:STATe.....	130
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:BCH:TYPE?.....	131
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:RMC.....	149
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SCCH.....	150
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:SPATtern?.....	150
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TBS:TABLE.....	150
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:TTIDistance.....	151
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:UEID.....	151
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:HSDPA:VIBSIZE.....	151
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:SSPattern.....	116
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TPCPattern.....	117
[:SOURCE<hw>]:BB:TDSCdma:DOWN:CELL<st>:ENH:DCH:PLCCh:TTIInterval?.....	117
[:SOURCE<hw>]:BB:TDSCdma:DOWN:PPARAmeter:PCCPch:STATe.....	111
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BIT:LAYer.....	118
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BIT:RATE.....	119
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BIT:STATe.....	119
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BLOCK:RATE.....	119
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BLOCK:STATe.....	119

[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:BPFRame?	120
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:CCOunt	120
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:CRCSIZE	120
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:DATA	121
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:DATA:DSElect	121
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:DATA:PATtern	122
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:EPRotectiOn	122
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:IONE	123
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:ITWO	123
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:RMATtribute	123
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:STATe	123
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:TBCount	123
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:TBSIZE	124
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:DTCH<ch> DCCH:TTINterval	124
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:BPAYload?	153
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:CRATE?	154
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:CTSCount	154
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:DATA	154
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:DATA:DSElect	155
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:DATA:PATtern	155
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:HARQ:LENGth	155
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:HARQ:MODE	156
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:MIBT?	156
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:MODulation	156
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:NCBTti?	157
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:RVParameter	157
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:RVSequence	157
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:SFORmat?	158
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:TBS:INDEx	158
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:TSCount	159
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:TTINterval?	159
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:HSDPA HSUPA:UECategory?	159
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:RUPLayer?	124
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:SCSMODE	125
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:SFORmat?	125
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:SLOTstate<ch>	125
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:STATe	125
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:TSCount	126
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:ENH:DCH:TYPE	126
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:MCODe?	112
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:PROTation	113
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SCODE	113
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SCODE:STATe	113
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SDCODe?	113
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DATA	134
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DATA:DSElect	134
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DATA:PATtern	134
[:SOURCE<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:SYNC: LENGth	135

[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:SYNC: PATtern.....	135
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:SYNC: REPetition.....	135
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:TFCl:LENGth	136
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:TFCl:VALue..	136
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:TPC:DATA....	136
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:TPC: DATA:DSElect.....	137
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:TPC: DATA:PATtern.....	137
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:TPC:READ...	137
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:ENHanced?.....	138
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:MSHift?.....	138
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:POWer.....	138
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SCODE.....	139
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SFACtor.....	139
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:SFORmat.....	139
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:STATe.....	140
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:TYPE.....	140
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:USER.....	140
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:DCONflict?.....	141
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SLOT<ch0>:STATe.....	141
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SPOint.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:STATE.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:SUCode.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:TDElay.....	114
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:CELL<st>:USERs.....	115
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:DPCH:COUNT.....	109
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:DPCH:CRESt.....	110
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:DPCH:SFACtor.....	110
[:SOURce<hw>]:BB:TDSCdma:DOWN UP:PPARAmeter:EXECute.....	111
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:APCO25.....	100
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:COsine.....	100
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:GAUSSs.....	101
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:LPASSs.....	101
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:LPASSEVM.....	101
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:PGAuss.....	101
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:RCOSine.....	102
[:SOURce<hw>]:BB:TDSCdma:FILTer:PARAmeter:SPHase.....	102
[:SOURce<hw>]:BB:TDSCdma:FILTer:TYPE.....	100
[:SOURce<hw>]:BB:TDSCdma:LINK.....	94
[:SOURce<hw>]:BB:TDSCdma:POWer:ADJust.....	94
[:SOURce<hw>]:BB:TDSCdma:POWer[:TOTal]?.....	94
[:SOURce<hw>]:BB:TDSCdma:PRAMp:BBONly.....	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:FDElay.....	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:RDElay.....	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:SHAPE.....	95
[:SOURce<hw>]:BB:TDSCdma:PRAMp:TIME.....	95
[:SOURce<hw>]:BB:TDSCdma:PRESet.....	96

[SOURce<hw>]:BB:TDSCdma:RESet.....	96
[SOURce<hw>]:BB:TDSCdma:SETTing:CATalog?.....	96
[SOURce<hw>]:BB:TDSCdma:SETTing:LOAD.....	97
[SOURce<hw>]:BB:TDSCdma:SETTing:STORe.....	97
[SOURce<hw>]:BB:TDSCdma:SETTing:TMODeL.....	97
[SOURce<hw>]:BB:TDSCdma:SETTing:TMODeL:CATalog?.....	97
[SOURce<hw>]:BB:TDSCdma:SLENgth.....	102
[SOURce<hw>]:BB:TDSCdma:STATe.....	98
[SOURce<hw>]:BB:TDSCdma:TRIGger:ARM:EXECute.....	103
[SOURce<hw>]:BB:TDSCdma:TRIGger:EXECute.....	103
[SOURce<hw>]:BB:TDSCdma:TRIGger:EXTernal:SYNChronize:OUTPut.....	104
[SOURce<hw>]:BB:TDSCdma:TRIGger:OBASeband:DELay.....	104
[SOURce<hw>]:BB:TDSCdma:TRIGger:OBASeband:INHibit.....	104
[SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:DELay.....	108
[SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:MODE.....	107
[SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:OFFTime.....	108
[SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:ONTime.....	108
[SOURce<hw>]:BB:TDSCdma:TRIGger:OUTPut<ch>:PERiod.....	108
[SOURce<hw>]:BB:TDSCdma:TRIGger:RMODE?.....	104
[SOURce<hw>]:BB:TDSCdma:TRIGger:SLENgth.....	105
[SOURce<hw>]:BB:TDSCdma:TRIGger:SLUNit.....	105
[SOURce<hw>]:BB:TDSCdma:TRIGger:SOURce.....	105
[SOURce<hw>]:BB:TDSCdma:TRIGger[EXTernal]:DELay.....	106
[SOURce<hw>]:BB:TDSCdma:TRIGger[EXTernal]:INHibit.....	106
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:ANPattern.....	117
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:CQI:MODulation.....	118
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:CQI:VALue.....	118
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSICh:TTINterval?.....	118
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:EUCTti.....	151
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:FRC.....	152
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSEQuence.....	152
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:RSNumber?.....	152
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:SFACTOR.....	153
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:ENH:DCH:HSUPA:TBS:TABLE.....	153
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:EUCC:CCOunt.....	132
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:EUCC:HPID.....	133
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:EUCC:RSNumber.....	133
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:CHANnel<us0>:DPCCh:EUCC:TFCI.....	133
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:MODE.....	141
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA.....	142
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:DSElect.....	142
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:DATA:PATtern.....	143
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:LENgth.....	143
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:MSHift?.....	143
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:PCORrection.....	143
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:POWER.....	144
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SCODE.....	144
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFACTOR.....	144
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:SFORmat?.....	145
[SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:STATe.....	145

[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:MSG:USER.....	145
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:DISTance.....	146
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:PCORrection?.....	146
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:POWer.....	146
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:PSTep.....	147
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:REPetition.....	147
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:PTS:STARt.....	147
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:SLOT<ch0>:PRAC:SLENgth?.....	148
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:MODE.....	111
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:POWer.....	112
[:SOURce<hw>]:BB:TDSCdma:UP:CELL<st>:UPPTs:STATe?.....	112
[:SOURce<hw>]:BB:TDSCdma:VERSion?.....	98
[:SOURce<hw>]:BB:TDSCdma:WAVeform:CREate.....	98
[:SOURce<hw>]:BB:TDSCdma[:TRIGger]:SEQuence.....	106

Index

A

ACK/NAK pattern	50
Activate Cell	33
Activate Slot	36
Adjust total power to 0 dB	30
Adjust Total Power to 0 dB	94
Application cards	8
Application notes	8
Arm	22
Armed_Auto	21
Armed_Retrigger	21
Auto	21

B

B x T	85
Baseband clipping	87
Baseband filter	85
Basic midamble code	11
Basic midamble code ID	33
BCH Slot	38
BCH spreading code selection	38
Bit error rate	51
Bit error state	50
Block error rate	51
Block error state	51
Brochures	8

C

Carrier spacing	11
Cell default values	28
Cell state	31
Channel Coding	38, 40
Channel number	67
Channel Power	68
Channel state	69
Channel Type	67
Channel types	11
Chip rate	11
Chip Rate	19
Chip rate variation	86
Clipping Level	87
Clipping Mode	87
Clipping state	87
Clock	
Mode	27
Source	27
Coding rate	60
Coding scheme	38, 40
Coding Type	38, 40
Common trigger settings	21
Conventions	
SCPI commands	91
Copy cell	29
Coupled trigger settings	21
CQI Modulation	49
CQI Value	49, 118
CRC	46, 126
Crest factor	87
Crest Factor	32
Cutoff frequency factor	86

D

Data bits per frame	39, 44
Data list	68
Data modulation	11
Data sheets	8
Data source	45, 58, 68
PRACH	83
Data Source	121, 127
DCH Slot	42
DCH spreading code selection	42
DCH state	40
Deactivate Cell	33
Deactivate Slot	36
Dedicated Slot Mode	64
Default settings	18, 28, 31
Default Settings	30
Delay	
Marker	26
Trigger	24
Distance UpPTS	81
Documentation overview	7
Domain conflict	69
Downlink	19
DPCCH Settings	69
DPCH spreading factor	32
DwPTS Mode	34
DwPTS Power	34

E

E-DCH fixed reference channel (FRC)	54
E-TFCI Value	77
Enhanced	67
Enhanced Channel Settings	35
Error Protection	46, 122
External trigger	
Delay	24

F

Fall Delay	90
Filter	11
Filter parameter	85
Filter Type	85
Frame structure	11

G

Generate	
Waveform file	19
Getting started	7
Guard period	36

H

HARQ Mode	62
HARQ Process ID	77
Help	7
HS-SCCH state	55

I

In Baseband Only	90
------------------------	----

Information bit payload	60
Insert bit errors	51
Insert errors	51
Installation	9
Instrument help	7
Instrument security procedures	8
Inter-TTI distance	61
Interleaver 1 state	47
Interleaver 2 state	47
L	
Link direction	19
M	
Marker delay	26
Marker mode	25
Maximum information bit throughput	56
Measured external clock	27
Message length	82
Midamble code ID	33
Midamble shift	84
Modulation	58
N	
Number of channels	11
Number of Channels (DCH)	43
Number of coded bits per TTI	59
Number of Dedicated Channels	32
Number of DPCHs	32
Number of E-DCH codes per TS	56
Number of E-DCH timeslots	56
Number of E-UCCH Channels	77
Number of E-UCCH per TTI	57, 151
Number of HARQ Processes	61
Number of HS-PDSCH codes per TS	56
Number of HS-PDSCH timeslots	56
Number of physical channel bits per E-UCCH	77
Number of sync Shift&TPC information bits	48
Number of sync shifts	75, 78
Number of TFCl bits	74
Number of Time Slots (DCH)	43
Number of TPC bits	75, 78
E-UCCH	78
Number of Users	35, 84
Nyquist filter	85
O	
Open source acknowledgment (OSA)	8
Options	31
P	
P-CCPCH state	38
Pattern	68
Phase rotation	34
Physical channels	11
Power Ramping	20
Power step	80
Power/dB	68
PRACH	64
PRACH message part power	83
PRACH Slot Mode	64
PRACH spreading factor	83
Predefined settings	31
Predefined Settings	30
R	
RACH message length	82
RACH state	82
Raised cosine filter	85
see Cosine filter	85
Ramp Function	89
Ramp Time	89
Rate Matching Attribute	46
Read out mode	79
Redundancy version parameter	63
Redundancy version sequence	63
Release notes	8
Repetition encoder	48
Reset cells	28
Resource Units On Physical Layer	41, 124
Retransmission sequence	63
Retransmission sequence number	63, 77
Retrigger	21
Rise Delay	90
RMC Configuration	52
Roll Off	85
Root raised cosine filter	85
see Root Cosine	85
RRC filter	85
see Root Cosine filter	85
S	
Safety instructions	8
Save/Recall	19
TD-SCDMA	19
Scrambling code	11, 33
Select Cell - BS	31
Select Slot	36
Select TPC list	78
Sequence Length	81
Sequence length (ARB)	88
Service manual	8
Set to default	18
Settings	31
Signal duration unit	22
Signal generation status	22
Signaling pattern	61
Single	21
Size of CDC	46, 126
Slot Configuration	36
Slot format	39, 43, 57, 67, 73
Slot Format	130
Slot format PRACH	83
Slot Mode	64
Slot Structure	73
Spreading code	11, 68
Spreading code PRACH	83
Spreading code selection	38, 42
Spreading factor	32
Spreading Factor	68
Spreading factor (FRC)	57
Standard settings	18
State	33
Cell	33
DCCH	44
DTCH	44
Slot	64

Switching point	36
Symbol rates	11
SYNC code	11
Sync shift pattern	48, 75
Sync shift repetition M	76
SYNC-DL code	34
SYNC-UL code	34
SYNC1 code	11
Synchronize Base Station to User Equipment	34
Synchronize user equipment to base station	34
System Chip Rate	19

T

Test Setup/Models	30
TFCI bits	74
TFCI Value	74, 136
Time Delay	35
Total number of Users	67
Total power	30
Total Power	30
TPC pattern	48, 78
TPC source	78
Transmission direction	19
Transmission Time Interval	57
Transport block size	46
Transport block size index	60
Transport block size table	59
Transport block size table 0	59
Transport blocks	46
Transport channel state	44
Transport time interval	45
Trigger	
Sync. output	23
Trigger delay	24
Trigger mode	21
Trigger signal duration	22
Trigger source	23
TTI	48, 49
Tutorials	7

U

UE category	56
UEID	55, 151
Uplink	19
UpPTS Mode	34
UpPTS Power	34, 81
UpPTS Power step	80
UpPTS repetition	82
UpPTS start	81
Use P-CCPCH	31
Use scrambling code	33
User	35
User manual	7

V

Version	19
Virtual IR buffer size	60

W

Waveform file	
Create	19
White papers	8